

**AM302**

**Start Here**




## OVERVIEW


**Please note**

All the functions in this manual should be operated in Standby Mode




Like the picture below.

Tips:


Press END  go back to the Standby Mode




### Make a call


Input the numbers, Press   
Send or answer a Call. Press the  to  
choose 1 or 2 card then Send. Press  off a  
call.

Tips:

\*Down Key to volume down. 

\*Up Key to volume up.

\*To unlock the keypad  > \*



### **Call logs**

OK> >OK

### **Dialed Calls**

OK> >ok>1

Display your recent dialed numbers.

### **Received Calls**

OK> >OK>2

Display your recent answered numbers.

### **Missed Calls**

OK> >OK>3

Display your recent missed numbers.

### **Rejected Calls**

OK> >OK>4

Display the incoming call records in the blacklist.

### **Delete All**

OK> >OK>5

You could delete all the records of the Dialed,  
Received, Missed and Rejected.

### Call timers

OK >  > OK > 6

Display Last Call, Received Calls, Dialed Calls,  
and All Calls. Press Left Soft Key to "Reset".

### Call Cost


OK >  > OK > 7

Press up/down navigation key to check: All  
Costs, Max Costs, Cost Rate, and Cost Reset.

### GPRS Counter

OK >  > OK > 8


Display Last sent, Last received, Total sent,  
and Total received. Press Left Soft Key to  
"Reset".



## Contacts

To browse the name card holder, store, edit and delete the names and phone numbers in the phone and SIM card.

Tips:

Press OK

### To Add:

Options>New

### To Edit

Choose the contact>Options>Edit


### To Delete

Choose the contact>Options>Delete



### Message

To receive and send the message.

Press  OK

### Write Message

To write new message.

### In box

Store the SMS and Push message

### Out box

Store the SMS you've sent in failure.

### Drafts

Store the SMS you've edited.

### Sent box

Store the SMS you've sent successfully.

Tip: Press # to select the desired input methods

Press \* to input symbols





### Internet

The device is compatible with WAP service.

You can visit news, weather forecast and airlines etc.

Press  >OK

\*Depends on network support.



## Multimedia

### FM Radio

Please connect with the earphone you can listen to Fm radio freely.

Press -OK


Tip: For the performance Multimedia function please insert the T-flash card.


\* to volume down..


# to volume up.■



## Calculator

Press  OK

Press the "  " in a few seconds, "." is shown on the screen.


Press the "  " in a few seconds, "-" is shown on the screen.



## Settings

You can customize the settings, such as time and date, language, call settings etc.

Tips:

Press OK >  > OK



**Ring settings:**

Right key>Choose the profiles.

To customize the ring settings

options>customize>ring settings.



**Thank you!**

**CAUTION!**

"Using the wrong type of battery,  
there is a danger of explosion."

"Must be in accordance bwith the  
disposal of used batteries."

**AMGOO**  
*just so good!*

For more info:  
[www.amgoo.com](http://www.amgoo.com)

2013 AMGOO Inc. All rights reserved.  
Rev:AM30220130515D  
Printed in China

**AM302**

**Empezar por aqui**





## Visión General


Por favor tenga en cuenta


Todas las funciones de este manual deben

realizarse en **Modo de espera**

Al igual que la imagen de abajo.

Consejos:

Tecla Finalizar  para Regresar al **Modo de espera**



**(Modo de espera)**

## Hacer una llamada

Introduzca los numeros y Presione la tecla




Llamar para elegir SIM1 o SIM2

**Contestar una llamada:** presione la tecla



llamar


**Presione la tecla**  para cortar o Rechazar la llamada.

Consejos:


\*Arriba Para subir el volumen.



\*Abaio Para bajar el volumen.

\*Presione la tecla Izquierda  >\*

Para bloquear el teclado



### Historial de llamadas

OK>  ->OK

### Llamadas hechas

OK>  ->ok>1

Muestra las ultimas llamadas hechas.

### Llamadas Recibidas

OK>  ->OK>2

Muestra todas llamadas recibidas.

### Llamadas pérdidas

OK>  ->OK>3

Registro de llamadas no contestadas.

### Llamadas rechazadas

OK>  ->OK>4

Muestra un registro de las llamadas rechazadas en la lista negra.

### Borrar todo

OK>  ->OK>5

Puede Eliminar todas las llamadas Hechas, recibidas, perdidas y rechazadas.

### Duracion de llamadas

OK>

Mostrar la última llamada, llamadas hechas, recibidas y todas las llamadas, presionar la tecla izquierda para "Reiniciar".

### Costo de llamadas

OK>


Presione las Arriba/Abajo en las teclas de navegacion para comprobar todos los costos, costo maximo Presione la tecla izquierda para "reiniciar".

### Contador de GPRS

OK>

Mostrar el ultimo envío, total enviados, total recibidos para Presione la tecla izquierda

"Reiniciar"



## Contactos

Para ver los contactos y números de teléfono,  
guardarlos, editarlos y borrarlos en el teléfono y  
en la tarjeta SIM.

### Consejos:

Presione  > OK

### Para añadir:


Opciones>Nuevo

### Para Editar

Elija el contacto>Opciones>Editar


### To Delete

Seleccione el contacto>Opciones>Borrar



## Mensajes

Para enviar y recibir y enviar mensajes.

Presione  OK

## Escribir mensajes

Para Escribir un Nuevo mensaje.

## Bandeja de entrada

Guarda los mensajes recibidos.

## Bandeja de salida

Guarda los SMS que no se han enviado.

## Borrador

Guarda los mensajes que as editado.

## Bandeja de salida

Guarda los SMS que se han enviado con éxito.

**Consejos: Presione # para seleccionar el**

**método de entrada Presione \* para**

**introducir símbolos.**



## Internet

El teléfono es compatible con el servicio WAP.

Puede ver las noticias, el pronóstico del tiempo,

aerolíneas, etc.

Presione  >OK

**\*Depende del soporte de la red.**






## Multimedia

Radio FM

Por favor conecte los Audifonos y podrá escuchar la radio FM gratuitamente.

Presione  >OK


Consejos: Para un mejor desempeño de funcion Multimedia por favor insertar la memoria Micro-SD.

Presione \* Bajar el volumen.

Presione # Subir el volumen.



## Calculadora

Presione  OK

Para Escribir un punto "." Presione la tecla "

 "."

Presione la tecla "" para introducir este signo "-"



## Configuración

Puede editar la configuración, como el día y la hora, el idioma, la configuración de las llamadas, etc.

Consejos:

Presione OK >  > OK




### Configuración de tono:

Tecla derecha> Seleccionar Perfiles.

Para personalizar el perfil

Opciones> Personalizar.



# Gracias!

## **PRECAUCION!**

"No utilizar baterias de otro tipo puede  
provocar una explosión"

"Debe ser de acuerdo con la disposición  
de las baterias usadas"

**AMGOO**  
*just so good!*

Para mas Información:  
[www.amgoo.com](http://www.amgoo.com)

AMGOO 2013. Todos los derechos reservados  
Rev:AM30220130515D  
Impreso en China

**Warning:**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules, These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new model phone is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the exposure limit established by the FCC, Tests for each phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC.

For body worn operation, this model phone has been tested and meets the FCC RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 1.5 cm from the body.

Non-compliance with the above restrictions may result in violation of RF exposure guidelines.