

<div data-bbox="295 94 389 121"><b>Dispho®</b></div> <div data-bbox="389 157 495 555"></div> <div data-bbox="366 596 529 641"><b>SKYPRINT TRIPOD</b> User Manual</div>	<div data-bbox="636 89 769 107"><b>Connect Bluetooth</b></div> <div data-bbox="636 111 944 200"><p>1. Press and hold the Capture Button for 3 seconds to power on. Enable the Bluetooth on the mobile phone to start searching and click "Dipho" on the searched device list. The green light will stay on after the connection is successful.</p><p>2. Go to Camera App mode and start to take selfies.</p></div> <div data-bbox="636 218 714 234"><b>User Notes</b></div> <div data-bbox="636 241 737 256"><b>Remote Control</b></div> <div data-bbox="636 258 940 320"><p>Take the remote control from the selfie stick for long-distance photographing.</p><p>Press the Capture Button to take a photo or record a video (under the REC mode).</p></div> <div data-bbox="636 329 680 344"><b>Tripod</b></div> <div data-bbox="636 345 907 376"><p>Unfold the tripod in the bottom, push the extendable stick up and place the tripod on a flat surface.</p></div> <div data-bbox="636 383 702 399"><b>Power Off</b></div> <div data-bbox="636 401 922 431"><p>Press and hold the Capture Button for 3 seconds and the green indicator will flash for 3 times before going off.</p></div> <div data-bbox="636 439 762 455"><b>Preventive Measure</b></div> <div data-bbox="636 456 905 487"><p>Do not move the phone by force after it's clamped in case of damage to the phone shell.</p></div> <div data-bbox="636 505 708 521"><b>Reminders</b></div> <div data-bbox="636 525 940 646"><p>1. In case of no operation within 10 minutes after Bluetooth is connected, the selfie stick will automatically enter the Sleep Mode. Press the Capture Button again to restore connection. In the event of no operation after 20 minutes in the Sleep Mode, the selfie stick will automatically power off.</p><p>2. In case of low battery during the use of the selfie stick, the indicator will turn red and flash. Please replace the battery in a timely manner</p></div>	<div data-bbox="982 100 1051 118"><b>Warnings</b></div> <div data-bbox="982 123 1283 243"><p>1. Watch your hands during use.</p><p>2. The product is not designed for children under 14 years old. Do not swallow it.</p><p>3. Do not dismantle or modify the product.</p><p>4. Do not store the product in a humid environment.</p><p>5. Keep the product away from heat sources.</p><p>6. Do not expose the product to water or other liquids in case of damage.</p></div> <div data-bbox="982 265 1070 281"><b>Fixed phone</b></div> <div data-bbox="1006 302 1065 593"></div> <div data-bbox="982 607 1122 637"><p>1. Insert the phone into the lower fixator slantwise.</p></div> <div data-bbox="1187 302 1246 593"></div> <div data-bbox="1144 607 1280 652"><p>2. Pull the upper fixator up to snap the phone into the holder.</p></div>
--	---	--

<div data-bbox="299 763 401 781"><b>Usage method</b></div> <div data-bbox="299 772 534 992"></div> <div data-bbox="426 969 588 1014"><p>1. Extend the selfie stick to the proper length and start to take selfies.</p></div> <div data-bbox="309 1064 401 1297"></div> <div data-bbox="433 1130 510 1189"></div> <div data-bbox="433 1189 574 1220"><p>Barrier-free Operation within 10 Meters</p></div> <div data-bbox="426 1232 596 1292"><p>2. Unfold the tripod, push the extendable stick up and place the tripod on a flat surface. Start to take selfies.</p></div>	<div data-bbox="633 763 744 781"><b>Replace Battery</b></div> <div data-bbox="633 786 942 831"><p>Take the remote control from the selfie stick, push the rear cover at the direction of the arrow, and take off the rear cover for battery replacement.</p></div> <div data-bbox="646 836 910 1010"></div> <div data-bbox="633 1025 766 1042"><b>Remove the phone</b></div> <div data-bbox="672 1051 871 1266"></div> <div data-bbox="633 1277 913 1324"><p>1. Hold the phone with one hand and pull the upper fixator up.</p><p>2. Slide the phone out.</p></div>	<div data-bbox="959 741 1286 775"><b>FCC ID:UR9WS-20001</b></div> <div data-bbox="972 781 1278 856"><p>The device has been evaluated to meet general RF exposure requirement, The device can be used in portable exposure condition without restriction. Federal Communication Commission (FCC) Radiation Exposure Statement. Power is so low that no RF exposure calculation is needed.</p></div> <div data-bbox="972 872 1281 897"><p>This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:</p></div> <div data-bbox="972 901 1278 947"><p>(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p></div> <div data-bbox="972 949 1273 1008"><p>NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.</p></div> <div data-bbox="972 1247 1278 1318"><p>Winners' Sun Plastic &amp; Electronics (Shenzhen) Co., Ltd. Production Address: 1/F-4/F of Factory 6 &amp; 3/F of Factory 2, Detai Industrial Park, 496 Huarong Road, Langkou Community, Dalang Sub-district, Longhua District, Shenzhen, Guangdong, China</p></div>
--	---	--