
Exhibit 1: ID label - location info





	Part Name Serial number label: Marine Reader					
	Part No.	Unit	Scale			
	ils-mr1	mm	1:1			
5	Drawn			Α	DIMS. & DWG. FRAME ADDED	05.07.07
				Issue	Description	Date

## **Example of FCC ID label location**



Located on a cable tag, as the back of the reader is too obtrusive to locate a suitable label.

