




SN4906312

6300000A







R52

U15

V02
11 01
X137

R64

R65

U17

R32

U16

Z1


U10


C65


R40


[Cfg]

R41









PCA CM-000516 Rev C
Mesa Labs 2022
Essentials Sensor

JTAG/JFI

BOOT

ETI-E2
94V-0
3022

J3

SW1

3.3V

TP18

TP10

TP11

TP12

TP13

TP14

TP15

TP16

TP17

TP18

TP19

TP20

TP21

TP22

TP23

TP24

TP25

TP26

TP27

TP28

TP29

TP30

TP31


TP32

TP33

TP34

TP35

TP36



3.3V
PCA CM-000516 Rev C
©Mesa Labs 2022
Essentials Sensor

TC2
[JTAG/IF]

BOOT


ETI-E2
94V-8
3022


PCB CM-000515 Rev C

PCA CM-000516

©Mesa Labs 2022

Essentials Sensor





C10

TP1

TP3

D4

TP11

C54

R56

Q2

D2

C29

U10

R27

R25

Q6

Q5

R5

TP9

R58

R38

R37

C30

L2

C31

R6

R2

D3

TP12

C19

U7

R20

C21

U12

C57

R21

C32

R22

U11

L4

C22

C42

C23

C4

U6

C56

L3

C33

Q3

B00T

R24

C42

C47

C44

C45

Y1

C40

TP10

C56

C34

C33

Q3

R29

R30

L9

C37

L10

C40

L9

L7

C38

C24

J4

D50

