

USING MANUAL HP-6001BT

Charge It

- On the right earcup, carefully plug the micro USB cable into micro USB charging port and connect the other end of the cable to either a computer USB port or to a USB-compatible car or wall charger.
- Solid red LED light will appear to indicate when the headphone is charging.
- When charging is complete, the LED light will turn off.
- Charging time is approximately 2 hours.

Turn It On/Off

- Press & hold the power button on the right side of the headphone for about 5 seconds.
- The headphone will emit a beep, and a blue LED light will light to indicate the headphone is turning on.
- To turn the wireless bluetooth headphone off, press & hold the power button again for 5 seconds until the LED light turns off.

Pair & Connect With New Device

- Power on the wireless bluetooth headphone (refer to the "Turn It On" section).
- To pair the headphone with a new device, the blue LED light blink to indicate it is ready to be paired with your device.
- On your Bluetooth-enabled smartphone, tablet or media player, navigate to the Bluetooth settings menu, turn on the Bluetooth feature, and search for new devices.
- After a few seconds you will see "6001BT" listed.
- Tap this model to select it. Solid blue LED light indicate your device has successfully paired.
- With your previously paired device's Bluetooth turned on and in range, The headphone will automatically reconnect to the last Bluetooth device it was connected to.
- You can also press and hold the Play button for 3 seconds to disconnect the AirLoop from the currently connected device. Then, follow the directions to connect your device again.

NOTE: If the headphone is not used within 10 minutes, the headphones will automatically turn off to save battery.

Play

- Connect your device to the headphone via Bluetooth (refer to the "Pair & Connect" section)
- Open your favorite music app and press play.
- Control the music, track & volume from your device, or control the music & volume from the touch screen (refer to the "touch function" . Press the Power button once to play/pause music & answer calls, press it twice to redial the last number called on your phone, and press & hold it to reject an incoming call.
- All audio, including music, games, videos, and notifications will be routed through the headphone.

USING MANUAL HP-6001BT

Touch Function

- Press&Hold A area (refer to product Diagram) to turn up the volume.
- Press&Hold B area (refer to product diagram) to turn down the volume.
- Press A area (refer to product Diagram) to switch to next track.
- Press B area (refer to product Diagram) to switch to previous track.

NOTE: Press gesture and touching the correct area will offer you fluently experience.

Troubleshooting

No power

Music is not playing over Bluetooth


Bluetooth device will not reconnect with the headphone

Recharge your wireless bluetooth headphone using the micro USB cable.

Make sure your Bluetooth device has A2DP profile. Check if both devices are paired and connected over Bluetooth. Restart the headphone to reconnect your Bluetooth device.

Navigate to your Bluetooth settings menu on your Bluetooth device, tap "6001BT", and select "Forget". Now follow the steps to pair your device again. Or, press & hold the power button on the headphone (while powered on) to disconnect the headphones from any connected devices. Then follow the steps to reconnect your device.

Product Diagram



Federal Communications Commission (FCC) Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications made to this device not expressly approved by SHENZHEN LISAIER TRONICS CO., LTD. may void the FCC authorization to operate this device.

Note: The manufacturer is not responsible for any radio or tv interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.