


HP-6111 Bluetooth Earbuds Instruction Manual



**** Please read all instructions prior to using the device.**

Bluetooth power ON/OFF:

1. Power on: Press and hold the multifunctional button for 3 seconds until the LED flashes blue 3 times.

HP-6111 Bluetooth Earbuds Instruction Manual

2. Power off: Press and hold the multifunctional button for 3 seconds to power off.
3. If the LED Indicator turns from BLUE to RED when in standby mode, turn the device off to conserve power.
4. Bluetooth pairing:
 - A. Press and hold the multifunctional button for 6 seconds. The LED Indicator flashes BLUE & RED to indicate pairing mode.
 - B. Activate the Bluetooth function on your mobile device and select " **HP-6111** " to pair. The mobile device indicates if pairing has been successful.

Answering calls:

Press the multifunctional button to answer an incoming call.

Ring off the call:

Press the multi-function button to hang up an active call.

Call back:

Press the multi-function button twice to redial the last caller's number.

Charging:

- Insert the micro-USB plug into the charging port and connect the opposite USB end to a computer or compatible AC wall adapter.
- The LED Indicator lights up RED while charging. The LED turns BLUE when the battery is full.

Volume control:

- Press the "+" button to increase the volume.
- Press the "-" button to reduce the volume.

Select previous/next track:

- Press and hold the "+" button to select the previous track.
- Press and hold the "-" button to select the next track.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.