



## 1. Photographs of Radiated Emissions Test Configuration

Test Mode: Mode 1 For EUT Y axis + Set 1 antenna Z axis

**FRONT VIEW**



**REAR VIEW**



**Test Mode: Mode 2 For EUT Z axis + Set 2 antenna Y axis**

**FRONT VIEW**



**REAR VIEW**



————THE END————