

## Set-up Procedure for R-FM96D

1. The receive antenna consists of 2 parts. By using tool like Figure 1, assemble 2 parts. Then, install the antenna on R-FM96D Receiver like Figure 2.



Figure 1



Figure 2

2. Put Power ON. Then, “Power” LED lights up and the receiver starts continuous receiving.

3. When it receives from the transmitter, “Signal” LED lights up. Note that “Signal” LED turns off in a second because it is controlled by timer, but the Receiver receives even if “Signal” LED turns off. There is no separate receive mode and no standby mode.