

IMPORTANT SAFETY INSTRUCTION

controls may result in damage and will and require extensive work by a qualified technician to restore in the product to its normal operation.

e) If the product has been dropped or the cabinet has been damaged.

f) When the product exhibits a distinct change in performance-this indicates a need for service.


25) Note to CATV system installer

This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

NOTE: Refer all servicing to qualified service personnel. Servicing is required when the unit has been damaged in any way such as the following: the power-supply cord or plug has been damaged, liquid has been spilled into the unit, the unit has been exposed to rain or moisture, the unit has been dropped or the unit does not operate normally.

Location of Controls:


1. BASS Control Knob
2. VOL (Volume) Control Knob
3. Indicators
4. Power ON/OFF Switch
5. DC IN Jack (DC \equiv 12V, 1A, \ominus \leftarrow \oplus)
6. AUX IN Jacks
7. Speaker Output Jacks



Power Source:

1. Insert the small plug from the supplied AC/DC Adaptor to the DC IN Jack on the unit.
2. Insert the AC/DC adaptor to a wall outlet having AC 100-240V~50/60Hz as the figure below:

NOTE: This AC/DC Adaptor is intended to be correctly orientated in a vertical or floor mount position.



Connections:

Connect the supplied speaker boxes to the main unit as the figure above.

OPERATION

BT (Blue Tooth):

In first time use or re-pairing to a new BT Device, pairing the unit to external BT Device as below:

1. Press the Power ON/OFF Switch to ON position. Blue Indicator will light and blinking.
2. Power on the external BT Device and enter to searching mode. Start pairing as the on screen instructions on the external BT Device. After paired, the Blue Indicator will stop blinking. (For details pairing procedures, please refer to the user's manual of your BT Device).

Notes:

- When the external BT player searched the unit, our model number “CHT756” will appear on the display of external BT Device.
- Pairing code “0000” or “1234” may need to enter.

Normal operation after pairing:

1. Turn on the BT function of the external BT Device.
2. Press the Power ON/OFF Switch to ON position to power on the unit. The Blue Indicator will light, wait until the Blue Indicator is stop blinking. (It needs take a few seconds).
3. Plays the music in the paired BT Device as usual.
4. During playback:
 - Turn the VOL (Volume) Control Knob to adjust volume level as desire.
 - Turn the BASS Control Knob to adjust bass (low audio frequency) level as desire.
5. When finished listening, press the Power ON/OFF Switch to OFF position to shut off the unit. The Blue Indicator will not light.

NOTE: If long period of time will not use, unplug the AC/DC Adaptor from wall outlet.



AUX IN:

To listen the music from external audio player such like ipad; ipod; cell phone; MP3 player; Discman ...:



1. Press the Power ON/OFF Switch to ON position to power on the unit. The Blue Indicator will light.
2. Connected one end of the supplied Audio Connection Cable to the 3.5mm stereo to the Phones Jack; Aux out Jack or Line Jack on the external player.
3. Connect the other end to the AUX IN Jack on the unit. The unit will turn to AUX IN mode automatically. The color of Blue Indicator will turns to Red.
4. Plays the Music in the connected audio player as usual. (Make sure the output level of the connected audio player is set to high. Otherwise, sound from this unit is weak.)
5. Turn the VOL (Volume) Control Knob to adjust volume level as desire.
6. Turn the BASS Control Knob to adjust bass (low audio frequency) level as desire.
7. When finished listening, unplug the Audio Connection Cable from the unit then press the Power ON/OFF Switch to OFF position to shut off the unit. The Blue Indicator will not light.

IMPORTANT: Make sure the Audio Connection Cable is unplugging from the unit before use BT. Otherwise, BT will not functioning.

General Specifications

Power Source:	DC  12V, 1A, 
Audio Power:	Total:9W(2+2+5W)
Impedance of speakers:	Subwoofer: 8 OHM; 15 W x 1 Left and Right speaker: 4 OHM; 5W x 2

Accessories:

1x User's Manual	
1x AC/DC Adaptor	Input: AC 100-240V~,50/60Hz, 0.5A; Output: DC  12V, 1A, 
1x Audio Connection Cable with 3.5mm Stereo Plugs	

SPECIFICATIONS AND ACCESSORIES ARE SUBJECT TO CHANGE WITHOUT NOTICE

LIMITED WARRANTY

Craig warrants this product to be free from manufacturing defects in material and workmanship under normal use for a period of 90 days from date of purchase. If service is required, please return the product to the store where it was purchased for exchange; or, pack the unit in the original packing material with all accessories if applicable, a copy of your sales receipt and a Cashier's check or Money Order for \$10.00 (to cover shipping and handling costs) payable to Craig Electronics Inc. For consumers in Canada, please make sure that the cashier check or money order is redeemable through a U.S. bank. Ship your product freight pre-paid. Your unit will be repaired, replaced or if the unit can not be repaired or replaced, a refund will be forwarded to you within four weeks of receipt of your unit. Please ship your unit to:

This warranty is void if the product has been: a) Used in a commercial application or rental. b) Damaged through misuse, negligence, or abuse. c) Modified or repaired by anyone other than an authorized Craig service center. d) Damaged because it is improperly connected to any other equipment.

Note: This warranty does not cover: a) Ordinary adjustments as outlined in the Owner's Manual which can be performed by the customer. b) Damage to equipment not properly connected to the product. c) Any cost incurred in shipping the product for repair. d) Damage to the product not used in the USA.

This warranty is not transferable and only applies to the original purchase. Any implied warranties, including the warranty of merchantability, are limited in duration to the period of this expressed warranty and no warranty whether expressed or implied shall apply to the product thereafter.

Under no circumstance shall Craig be liable for any loss or consequential damage arising out of the use of this product. This warranty gives specific legal rights. However, you may have other rights which may vary from state to state. Some states do not allow limitations on implied warranties or exclusion of consequential damage. Therefore, these restrictions may not apply to you.