

## Wireless for HDMI Sender Wireless for HDMI Receiver

### **GTW-WHD-1080P-SRS**



Congratulations on your purchase of the Wireless for HDMI Extender. Your complete satisfaction is very important to us.

#### **The GefenTV Wireless for HDMI Extender**

The GefenTV Wireless for HDMI Extender system sends high definition audio and video to any HDTV display up to 80 feet (25 meters) away. It extends HDMI A/V content from computers with HDMI output, set-top boxes, Blu-ray players, and other A/V sources to an HDMI compliant display. This product is comprised of a small Sender unit that plugs directly into an HDMI port, and one table-top Receiver unit. It can extend HD resolutions up to 1080p Full HD along with up to 7.1-channels of digital audio in PCM, Dolby®, or DTS® formats. The Wireless for HDMI Extender transmits through walls and does not require line-of-sight placement of transceivers for good reception. Thanks to its small form-factor, easy to plug in Sender unit, it is ideal for connecting a lap-top computer or video camera to an existing A/V system in a conference room environment.

#### **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### Start Here

Make sure you have everything that came with your product:

#### Item

- (1) Wireless for HDMI Extender (Sender Unit)
- (1) Wireless for HDMI Extender (Receiver Unit)
- (1) 5 ft. HDMI Cable (M-M)
- (1) USB to Mini USB Cable
- (1) IR Remote Control
- (1) Cradle for Receiver Unit
- (1) 5V/1A DC Power Supply (for Sender Unit)
- (1) 5V/2A DC Power Supply (for Receiver Unit)
- (1) Quick-Start Guide



If any of these items are missing from your product, call Gefen Technical Support between 8:00 AM to 5:00 PM Monday through Friday, Pacific Time. Refer to the last page of this Quick-Start Guide for contact information.



**NOTE:** The User Manual and Warranty information for this product can be downloaded from the support section on the Gefen Web site. You can also download the manual by scanning the QR code above.




### Installation Input

1

1. Plug the Sender directly into the HDMI output of an HDMI source.



2. When using a PC as the source, connect the supplied USB-to-mini-USB cable from the PC to the Sender unit.



If the source does not have a USB port that can provide power to the Sender unit, connect the 5V/1A power supply.

### Output and Power

3. Connect the included HDMI cable from the HDMI output on the Receiver unit to the HDMI input on the HDTV display.



4. To power-on the Receiver unit, connect the included power supply and plug the power cord into an available electrical outlet.



# 2

### Pairing

5. Turn on the display and wait 15 to 25 seconds for the link and video indicators to turn on. A message indicating that the Sender and Receiver units are paired should appear on the display.



6. If the Sender and Receiver units do not pair automatically, point the IR remote at the IR sensor window on the Receiver and press Menu. Navigate through the on-screen menu and have the Receiver look for a Sender. Press and hold the pairing button on the Sender until the Link LED stops blinking. Press OK on the remote. A message indicating that the Sender and the Receiver have been paired will appear on the display.



# 3

**Gefen tv**®**Gefen  
TOOLBOX****Gefen PRO**®**Gefen DS**  
Digital Signage**FCC Radiation Exposure Statement**

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

**Caution!**

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

**Technical Support:**

(818) 772-9100  
(800) 545-6900

Fax: (818) 772-9120

Gefen, LLC  
c/o Customer Service  
20600 Nordhoff St  
Chatsworth, CA 91311

[support@gefentv.com](mailto:support@gefentv.com)

**Technical Support Hours:**

8:00 AM to 5:00 PM Monday through Friday, Pacific Time

**Wireless for HDMI Extender** is a trademark of Gefen, LLC

Gefen, LLC reserves the right to make changes in the hardware, packaging, and any accompanying documentation without prior written notice.

© 2012 Gefen, LLC. All rights reserved.

All trademarks are the property of their respective owners.

All features and specifications are subject to change without notice.



This product uses UL or CE listed power supplies.



\* Q S G - G T V - W H D - 1 0 8 0 P - S R \*

**Rev A5**