

**1. External Photograph of EUT**

**Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100**



Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100





**2. Photograph of Accessory**

**Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100**

<b>Specification of Accessory</b>		
<b>Battery</b>	<b>Brand Name</b>	Zebra
	<b>Model Name</b>	BT000296A01
<b>USB Cable</b>	<b>Brand Name</b>	Zebra
	<b>Model Name</b>	HS3100-CHUC1-01

**Remark:** For accessories equipped with this EUT, please refer to the following photos.

Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100




Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100



Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100



Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100



Brand Name: Zebra / Model Name: HS3100 / Marketing Name: HS3100

