



1. External Photograph of EUT

Brand Name: Zebra / Model Name: MC27AK





Brand Name: Zebra / Model Name: MC27AK





Brand Name: Zebra / Model Name: MC27AK



Brand Name: Zebra / Model Name: MC27AK



Brand Name: Zebra / Model Name: MC27AK



Brand Name: Zebra / Model Name: MC27AK





2. Photograph of Accessory

Brand Name: Zebra / Model Name: MC27AK

Specification of Accessory		
AC Adapter	Brand Name	Zebra
	Part Number	PWR-WUA5V12W0US
Battery	Brand Name	Zebra
	Part Number	BT-000418-10
USB Cable (TypeA plug to TypeC plug)	Brand Name	Zebra
	Part Number	CBL-TC2X-USBC-01
Trigger Handle	Brand Name	Zebra
	Part Number	TRG-MC2X-SNP1-01
Holster	Brand Name	Zebra
	Part Number	SG-MC2X-HLSTR-01
Holster	Brand Name	Zebra
	Part Number	SG-MC3021212-01R

Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: Zebra / Model Name: MC27AK



Brand Name: Zebra / Model Name: MC27AK

AC Adapter



Brand Name: Zebra / Model Name: MC27AK

Battery

