

1. External Photograph of EUT

Brand Name: Zebra / Model Name: MC330K

SKU 1



Brand Name: Zebra / Model Name: MC330K



**Brand Name: Zebra / Model Name: MC330K**



Brand Name: Zebra / Model Name: MC330K





**Brand Name: Zebra / Model Name: MC330K**



Brand Name: Zebra / Model Name: MC330K



Brand Name: Zebra / Model Name: MC330K



Brand Name: Zebra / Model Name: MC330K







Brand Name: Zebra / Model Name: MC330K

SKU 2



**Brand Name: Zebra / Model Name: MC330K**





**Brand Name: Zebra / Model Name: MC330K**



Brand Name: Zebra / Model Name: MC330K





**Brand Name: Zebra / Model Name: MC330K**



Brand Name: Zebra / Model Name: MC330K



Brand Name: Zebra / Model Name: MC330K



Brand Name: Zebra / Model Name: MC330K





Brand Name: Zebra / Model Name: MC330K

SKU 3



Brand Name: Zebra / Model Name: MC330K



**Brand Name: Zebra / Model Name: MC330K**



Brand Name: Zebra / Model Name: MC330K



Brand Name: Zebra / Model Name: MC330K



Brand Name: Zebra / Model Name: MC330K





Brand Name: Zebra / Model Name: MC330K



Brand Name: Zebra / Model Name: MC330K







2. **Photograph of Accessory**

**Brand Name: Zebra / Model Name: MC330K**

<b>Specification of Accessory</b>		
<b>AC Adapter 1</b>	<b>Brand Name</b>	Zebra
	<b>Part Number</b>	PWR-BGA12V108W0WW
<b>AC Adapter 2</b>	<b>Brand Name</b>	Zebra
	<b>Part Number</b>	PWR-WUA5V12W0US
<b>MC32 1X Battery</b>	<b>Brand Name</b>	Symbol
	<b>Model Name</b>	82-000011-01
<b>MC32 2X Battery</b>	<b>Brand Name</b>	Symbol
	<b>Model Name</b>	82-000012-02
<b>Sentry 1X Battery</b>	<b>Brand Name</b>	Zebra
	<b>Part Number</b>	BT-000338-01
<b>Sentry 2X Battery</b>	<b>Brand Name</b>	Zebra
	<b>Part Number</b>	BT-000337-01
<b>U cable</b>	<b>Brand Name</b>	N/A
	<b>Model Name</b>	N/A

**Remark:** For accessories equipped with this EUT, please refer to the following photos.

Brand Name: Zebra / Model Name: MC330K

SKU 1



Brand Name: Zebra / Model Name: MC330K

SKU 2



Brand Name: Zebra / Model Name: MC330K

SKU 3



Brand Name: Zebra / Model Name: MC330K

Adapter 1



Brand Name: Zebra / Model Name: MC330K




Brand Name: Zebra / Model Name: MC330K




Brand Name: Zebra / Model Name: MC330K

Adapter 2





Brand Name: Zebra / Model Name: MC330K




Brand Name: Zebra / Model Name: MC330K



Brand Name: Zebra / Model Name: MC330K

MC32 1X Battery



Brand Name: Zebra / Model Name: MC330K




Brand Name: Zebra / Model Name: MC330K



Brand Name: Zebra / Model Name: MC330K

MC32 2X Battery



Brand Name: Zebra / Model Name: MC330K



Brand Name: Zebra / Model Name: MC330K





Brand Name: Zebra / Model Name: MC330K

Sentry 1X Battery



Brand Name: Zebra / Model Name: MC330K



Brand Name: Zebra / Model Name: MC330K



Brand Name: Zebra / Model Name: MC330K

Sentry 2X Battery



Brand Name: Zebra / Model Name: MC330K



Brand Name: Zebra / Model Name: MC330K

