



1. External Photograph of EUT

Brand Name: Zebra / Model Name: MC330K

SKU 11





**Brand Name: Zebra / Model Name: MC330K**





**Brand Name: Zebra / Model Name: MC330K**





**Brand Name: Zebra / Model Name: MC330K**



Brand Name: Zebra / Model Name: MC330K



Brand Name: Zebra / Model Name: MC330K



Brand Name: Zebra / Model Name: MC330K



**Brand Name: Zebra / Model Name: MC330K**

**2. Photograph of Accessory****Brand Name: Zebra / Model Name: MC330K**

Specification of Accessory		
AC Adapter 1	Brand Name	Zebra
	Part Number	PWR-BGA12V108W0WW
AC Adapter 2	Brand Name	Zebra
	Part Number	PWR-WUA5V12W0US
MC32 1X Battery	Brand Name	Symbol
	Model Name	82-000011-01
MC32 2X Battery	Brand Name	Symbol
	Model Name	82-000012-02
Sentry 1X Battery	Brand Name	Zebra
	Part Number	BT-000338-01
Sentry 2X Battery	Brand Name	Zebra
	Part Number	BT-000337-01
U cable	Brand Name	N/A
	Model Name	N/A

**Remark:** For accessories equipped with this EUT, please refer to the following photos.



Brand Name: Zebra / Model Name: MC330K

SKU 11





Brand Name: Zebra / Model Name: MC330K

Adapter 1




**Brand Name: Zebra / Model Name: MC330K**

Brand Name: Zebra / Model Name: MC330K




Brand Name: Zebra / Model Name: MC330K

Adapter 2



Brand Name: Zebra / Model Name: MC330K




Brand Name: Zebra / Model Name: MC330K





**Brand Name: Zebra / Model Name: MC330K**

**MC32 1X Battery**



Brand Name: Zebra / Model Name: MC330K



Brand Name: Zebra / Model Name: MC330K






Brand Name: Zebra / Model Name: MC330K

MC32 2X Battery



Brand Name: Zebra / Model Name: MC330K



Brand Name: Zebra / Model Name: MC330K





Brand Name: Zebra / Model Name: MC330K

Sentry 1X Battery



Brand Name: Zebra / Model Name: MC330K



Brand Name: Zebra / Model Name: MC330K





**Brand Name: Zebra / Model Name: MC330K**

**Sentry 2X Battery**



Brand Name: Zebra / Model Name: MC330K



Brand Name: Zebra / Model Name: MC330K

