



1. External Photograph of EUT

Brand Name: ZEBRA; Model Name: PS30JB





Brand Name: ZEBRA; Model Name: PS30JB





Brand Name: ZEBRA; Model Name: PS30JB





Brand Name: ZEBRA; Model Name: PS30JB



Brand Name: ZEBRA; Model Name: PS30JB



Brand Name: ZEBRA; Model Name: PS30JB





2. Photograph of Accessory

Brand Name: ZEBRA; Model Name: PS30JB

List of Accessory:

Specification of Accessory				
Battery 1	Brand Name	Zebra	Part Number	BT-000355-0020
Battery 2	Brand Name	Zebra	Part Number	BT-000355-5020

Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: ZEBRA; Model Name: PS30JB





Brand Name: ZEBRA; Model Name: PS30JB



Brand Name: ZEBRA; Model Name: PS30JB



Brand Name: ZEBRA; Model Name: PS30JB