



1. External Photograph of EUT

Brand Name: ZEBRA; Model Name: PS30JP





Brand Name: ZEBRA; Model Name: PS30JP



Brand Name: ZEBRA; Model Name: PS30JP



Brand Name: ZEBRA; Model Name: PS30JP





Brand Name: ZEBRA; Model Name: PS30JP





Brand Name: ZEBRA; Model Name: PS30JP





2. Photograph of Accessory


Brand Name: ZEBRA; Model Name: PS30JP

List of Accessory:

Specification of Accessory				
Battery 1	Brand Name	Zebra	Part Number	BT-000355-0020
Battery 2	Brand Name	Zebra	Part Number	BT-000355-5020


Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: ZEBRA; Model Name: PS30JP





Brand Name: ZEBRA; Model Name: PS30JP



Brand Name: ZEBRA; Model Name: PS30JP



Brand Name: ZEBRA; Model Name: PS30JP

