

1. External Photograph of EUT

Brand Name: Zebra / Model Name: TC26BK

Sample 1



Brand Name: Zebra / Model Name: TC26BK



**Brand Name: Zebra / Model Name: TC26BK**



**Brand Name: Zebra / Model Name: TC26BK**



Brand Name: Zebra / Model Name: TC26BK



**Brand Name: Zebra / Model Name: TC26BK**



**2. Photograph of Accessory**
**Brand Name: Zebra / Model Name: TC26BK**

Specification of Accessory		
AC Adapter	Brand Name	Zebra
	Part Number	PWR-WUA5V12W0US
Battery 1	Brand Name	Zebra
	Part Number	BT-000409-00
Battery 2	Brand Name	Zebra
	Part Number	BT-000409-50
Battery 3	Brand Name	Zebra
	Part Number	BT-000411-08
USB Cable 1 (Type A plug to Type C plug)	Brand Name	Zebra
	Part Number	CBL-TC5X-USBC2A-01
USB Cable 2 (Type A plug to Type C plug)	Brand Name	Zebra
	Part Number	CBL-TC2Y-USBC90A-01
Headset 3.5mm type with PTT/micassy	Brand Name	Zebra
	Part Number	HDST-35MM-PTVP-01
Adapter Cable PTT headset (3.5mm to 3.5mm)	Brand Name	Zebra
	Part Number	CBL-TC51-HDST35-01
Snap on Trigger handle	Brand Name	Zebra
	Part Number	TRG-TC2Y-SNP1-01
Belt Holster	Brand Name	Zebra
	Part Number	SG-TC2Y-HLSTR1-01
Wearable Arm Mount	Brand Name	Zebra
	Part Number	SG-TC2Y-ARMNT-01

**Remark:** For accessories equipped with this EUT, please refer to the following photos.

Brand Name: Zebra / Model Name: TC26BK





Brand Name: Zebra / Model Name: TC26BK

AC Adapter



Brand Name: Zebra / Model Name: TC26BK

Battery 1



Brand Name: Zebra / Model Name: TC26BK

Battery 2



Brand Name: Zebra / Model Name: TC26BK

Battery 3

