

1. External Photograph of EUT


Brand Name: Zebra / Model Name: TC720L




Brand Name: Zebra / Model Name: TC720L



Brand Name: Zebra / Model Name: TC720L



Brand Name: Zebra / Model Name: TC720L





Brand Name: Zebra / Model Name: TC720L



Brand Name: Zebra / Model Name: TC720L



2. Photograph of Accessory

Brand Name: Zebra / Model Name: TC720L

Specification of Accessory		
AC Adapter	Brand Name	Zebra
	Part Number	PWR-BUA5V16W0WW
4 PIN DC power cable	Brand Name	Zebra
	Part Number	CBL-DC-383A1-01
AC Power cable	Brand Name	Zebra
	Part Number	50-16000-182R
Snap-On USB/Charge Cable	Brand Name	Zebra
	Part Number	CBL-TC7X-USB1-01
Snap-On Charging Cable Cup	Brand Name	Zebra
	Part Number	CHG-TC7X-CBL1-01
Battery 1	Brand Name	Zebra
	Part Number	BT-000318-01
Battery 2 (Falcon 1S3P Battery Pack)	Brand Name	Zebra
	Part Number	BT-000318-51
Battery 3	Brand Name	Symbol
	Part Number	82-171249-02
Earphone 1	Brand Name	Zebra
	Part Number	HDST-35MM-PTVP-01
Earphone 2	Brand Name	Zebra
	Part Number	HS2100-OTH
Snap-on 3.5MM Audio Jack Adapter	Brand Name	Symbol
	Part Number	ADP-TC7X-AUD35-01
3.5mm Jack 43"(1.1m) Standard Cable	Brand Name	Zebra
	Part Number	CBL-HS2100-3MS1-01
Holster	Brand Name	Zebra
	Part Number	SG-TC7X-HLSTR1-02
Rigid Holster	Brand Name	Zebra
	Part Number	SG-TC7X-RHLSTR1-01

Remark: For accessories equipped with this EUT, please refer to the following photos.

Brand Name: Zebra / Model Name: TC720L




Brand Name: Zebra / Model Name: TC720L

AC Adapter



Brand Name: Zebra / Model Name: TC720L

Battery 1



Brand Name: Zebra / Model Name: TC720L

Battery 2



Brand Name: Zebra / Model Name: TC720L

Battery 3

