




APPENDIX SETUP PHOTOS

RADIATED MEASUREMENT SETUP

Normal Operating Mode





Charging Mode (From Notebook PC)



Charging Mode (From Power Adapter)








RADIATED RF MEASUREMENT SETUP







RF PORT COUNTED MEASURE SETUP





POWERLINE CONDUCTED EMISSIONS MEASUREMENT SETUP

Charging Mode (From Notebook PC)





Charging Mode (From Power Adapter)

