
Front Back

# Fame Bluetooth Speaker Instruction Manual SM-3955

Thank you for choosing our wireless Bluetooth Speaker! Before you use the speaker make sure to completely charge the device, and become familiar with the Bluetooth functions on your paired devices.

### How to use the Bluetooth Speaker

#### A. The General Features



### 1. On/Off Switch

Switch the On/Off button from left to right to power the device ON or OFF

### Charging & Line-in interface

 Make sure to charge device while not in use. Plug the USB power or adapter power to charge the speaker.

#### PREV/Volume Plus Button

Click the "+" button to play the previous track. Hold in the "+" to add volume

#### 4. NEXT/Volume Less Button

Click the "-" button to play the next track. Hold in the "-" to lessen the volume

### Pairing with Mobile Device

The speaker needs to be connected with a Mobile Device to use the wireless Bluetooth functions. If the mobile device has paired with a bluetooth speaker previously, the match will finish automatically.

- Activate Bluetooth mode on mobile device and turn speaker ON. Speaker will automatically enter pairing mode.
- · Search for the Bluetooth Speaker from your mobile device
- Mobile device will display the Bluetooth speaker as "Fame" in list of available devices. Select pair.
- Follow instruction on mobile device to complete pairing. If pass-code is needed, enter "0000"
- After the Mobile Device and Bluetooth Speaker connect, sound can be controlled from the Volume Buttons (3, 4).

### Technology Specifications

| Parameters              | Index        |
|-------------------------|--------------|
| Bluetooth specification | 2.1 + EDR    |
| Bluetooth protocol      | RDA 5851S    |
| Communication distance  | 5 M          |
| Frequency response      | 150Hz-20KHZ  |
| Horn Output power       | 3W           |
| Signal-to-noise ratio   | ≥80dB        |
| Distortion              | ≤1.0%        |
| Playing time            | 2 to 3 hours |
| Charging time           | 3 to 4 hours |

## Safety Information:

- · Avoid contact with liquids and damp areas
- Charge battery fully before use
- · If speaker is damaged seek professional consultation, do not repair.
- · Do not take speaker apart to avoid electrocution.
- Keep speaker away from flame.
- · Keep out of reach of children.

### **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.