

PHOTOS: RADIATED EMISSIONS: EUT SET UP

Notes: Receive antennas located outside weather dome 3 meters away from EUT.



PHOTOS: CONDUCTED EMISSIONS: EUT SET UP

Notes:



PHOTOS: RADIATED FIELD STRENGTH OF SPURIOUS EMISSIONS

Notes: Transmit Antenna




PHOTOS: RADIATED FIELD STRENGTH OF SPURIOUS EMISSIONS

Notes: Transmit Antenna



PHOTOS: RADIATED FIELD STRENGTH OF SPURIOUS EMISSIONS

Notes: Receive Antenna



**PHOTO: RF POWER OUTPUT, EMISSIONS LIMITATIONS
GSM/TDMA, OCCUPIED BANDWIDTH GSM/TDMA,
CONDUCTED SPURIOUS EMISSIONS AT ANTENNA
TERMINALS**

Notes:

