

1.5 User Manual

QUICK GUIDE TO THE BLUETOOTH KEYBOARD



FCC ID: V77Z2W6008403


This device complies with Part 15 of the FCC Rules:

Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference that is received, including any interference that may cause undesired operation.

Installing the wireless keyboard

1. Slide the Phone into the wireless keyboard at an angle.



2. Gently press the opposite edge of the Phone down to securely snap it into the wireless keyboard.



Initial Setup

1. On the Phone, SELECT settings-general-bluetooth and set the Bluetooth to "ON" to search for nearby devices.



2. On the wireless keyboard, slide the power switch to the "ON" position.
3. Activate the Bluetooth pairing button with a small reset pin or tool—a blue LED light will be lit on the wireless keyboard.



4. "Bluetooth Keyboard" will appear on your phone as one of the Bluetooth devices available.
5. Select "Bluetooth Keyboard". A notification will appear prompting the password to pair the wireless keyboard with your phone.
6. Enter the password on the wireless keyboard, then press "enter".





Congratulations! Your phone is now successfully paired with the wireless keyboard.

Getting to know your wireless keyboard



1. Slide Out Keyboard-Slide your phone upwards to begin typing on the keyboard.
2. Home Button-Press the Home Button to return your phone to the home screen.
3. Shift Button-Hold down the Shift Button along with the white symbols shown on the upper left-hand corner of the keys.
4. Fn Button-Hold down the Fn Button along with a blue symbols shown on the upper left-hand corner of the keys.
5. Toggle On Screen Keyboard-Press Fn-Toggle Keyboard to activate or deactivate the on screen keyboard.



6. Search Button-Press the Search Button to activate the search screen on your phone.
7. Change Language-Press Fn-Language to select the language previously activated on your phone.
8. Connection indicator LED-Blue LED Blinking, the ongoing connection pair.
9. Low battery indicator LED-Yellow LED Blinking, the keyboard battery is low, please charge the keyboard.
10. Charge indicator LED -The LED light is red when it is charged; The LED light is green when it is fully charged.
11. Power Switch - Slide the Power Switch to turn your wireless keyboard On and Off.
12. Charging Port - Connect the wireless keyboard to any USB power source using the included charging cable to charge.
13. Wireless pairing button- Use a small reset pin to activate search mode.

Charging the battery

1. For the first time user, Please charge the keyboard for at least 6 hours before using it. Thereafter, charge for at least 2 hours when the battery runs low.
2. Connection Charging Cable.



Quick trouble shooting tips

If the keyboard is not working with the phone make sure:

1. Check power switch on the wireless Keyboard
2. The Bluetooth function on the phone is enabled.
3. The passkey is entered correctly.
4. Reboot phone - Hold home button and sleepbutton for 5 seconds.
5. Make sure your phone has sufficient charge.
6. Make sure Airplane mode is turned off.
7. Battery which built-in keyboard in low power station, please charge it.

Product Specifications

- Bluetooth Specification: Version 2.0 Class 2
- Range of Frequency: 2.4GHz Spectrum
- Operating Voltage: 3.7Vdc (powered by Li-ion)
- Standby Current: 1.2mA
- Operation Current: < 5mA
- Sleep Current: < 0.7mA

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.