



Jumper = Reset
No Jumper = No Reset

Jumper = PA
No Jumper = No PA

Channel LED

Modulation LED

Autani
Dual Footprint
Base Board

Channel Button

Modulation Button

