Instruction Manual for RF Remote Socket and Transmitter


Ref: EMW202T + EMW202US/RF

Function

- 1. The remote control socket turns on and off the connected lighting or appliance by a wireless transmitter using radio frequency up to **80** feet away.
- 2. It is ideal for lighting control, for the purposes of home automation and energy saving.
- 3. The receiver has the indicator light for power supply status.
- 4. The transmitter is with key chain hole for convenience use.

Operation

- 1. No setting is required.
- 2. Connect the remote control socket to the power supply.
- 3. Turn off the appliance before connecting to the remote control.
- 4. Remove the plastic tab at the battery holder on the transmitter to allow battery contact.
- 5. Press the corresponding "ON", "OFF" button on the transmitter to switch on and off the connected appliance by remote control
- 6. The indicator on the transmitter blinks once for every transmission of power on/off
- 7. When the indicator light on the transmitter dims, battery changing is recommended. Open the battery holder (as per below figure) and replace it.



Caution

- 1. Always switch off your appliance before connection.
- 2. For INDOOR USE ONLY
- 3. Appliances to be connected to the remote control socket **MUST NOT** exceed the voltage and frequency ratings as in "Specifications".

Specifications EMW202US/RF

- 1. Power Rating: 120VAC, 60Hz,
- 2. Resistive load: 1000W max.
- 3. Frequency: : 433.92 MHz
- 4. Distance: : up to 80 feet in open area

EMW202T

- 1. Battery : CR2032 3VDC (included)
- 2. Frequency : 433.92 MHz
- 3. Distance : up to 80 feet in open area

Manufacturer

K EverFlourish

Everflourish Electrical Co., Ltd. Renjiu Village, Wuxiang Town, Yinzhou Ningbo 315111 P.R. China

Caution:

This device complies with Part 15 of the FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. **Prudence**:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.