

尺寸是145\*110MM  
材质是128G铜版纸印刷

BEAUTY SPEAKER

audio amplifier ①

Congratulations on your purchase of this outdoor wireless audio system. Before you use, please read this manual carefully. It contains important operating instructions

**Warning:**

- \* Do not expose the system in extremely hot or humid environment. Furthermore, do not place the system in storm. If you are not going to use the system for a long time, ensure to disconnect it from the wall outlet or remove battery.
- \* Place the system in a flat, dry surface with adequate ventilation.
- \* Please use good quality battery and do not mix new and old batteries. To prevent possible hazard, do not dispose battery in the fire. The battery must be recycled or disposed properly.
- \* Please use enclosed AC adapter (Universal).
- \* To avoid the risk of electric shock, do not remove cover (or back). Refer servicing to qualified personnel only.

**Special Features:**

- \* The system is equipped with high quality amplifier and speakers. This provides clarity in tremble, well-rounded in mid tone, and powerful in bass. This will easily meet your expectation on sound quality.
- \* Three-channel selection on both the system and signal transmitter allows direct connection to any sound frequency or input from any wireless signal transmitter. The valid transmitting distance is 150 feet. (Under no obstacles)
- \* The system is equipped with power saving function. When battery is low, the power light on the system will turn to pink and change to power saving mode.
- \* Control panel is made with soft touch buttons. All buttons are lighted for easy operation.

**Components:**


System Unit	1
Connecting Cord	2
AC Adapter	2
Signal Transmitter	1
Instruction Manual	1
Warranty Card	1

BEAUTY SPEAKER

audio amplifier ②

**Functions:**

- 1.....System/Main Unit
- 2.....Tremble Speaker
- 3.....Bass Speaker
- 4.....Volume Control
- 5.....Power Control
- 6.....Bass Increase Control
- 7.....Display Light Control
- 8.....Volume Control Indicator
- 9.....Power Control Indicator
- 10.....Bass Amplifier Indicator
- 11.....Display Light Indicator





BEAUTY SPEAKER


audio amplifier ③

**Functions:**

- 12.....Battery Cover
- 13.....Battery Cover Lock
- 14.....Receiver Channel Selector (CH)
- 15.....DC Power In
- 16.....AUX In



**System Setup:**




System:  
The system can connect directly to devices with audio output such as iPod, DVD, VCD, CD, and MP3 thru AUX IN. Once those devices are connected, signals will not be accepted from the transmitter.

BEAUTY SPEAKER

audio amplifier ⑤

**Signal Transmitter Setup:**

Signal Transmitter:  
Allow direct connection to devices with audio output functions such as iPod, DVD, VCD, CD, and MP3.



**System Specifications:**

Power Output:	.....(THD10%) 15W+3W
Frequency Response:	.....80Hz-20KHz(±0dB)
Carrier Frequency:	.....92.8-927.4 MHz
Power Source:	.....Unregulated 12V DC, Center Tip set to positive (+), 100mA
Modulation Method:	.....FM Modulation
AUX Input Sensitivity:	.....1000mV
Noise Ratio:	.....75dB
Tremble Speaker Dimension:	.....7"
Bass Speaker Dimension:	.....1.5"
Speaker Impedance:	.....4ohm
Dimensions:	.....H380* W210* L230
Battery Specification:	.....D
Weight:	.....3kg

**Setup Instruction:**

1. Connect the power adaptor of the system to AC wall outlet and place the other end to DC output at the back of the system. If use battery, place batteries in compartment. If both batteries and AC power are in place, the system will automatically obtain electricity from the AC outlets.
2. Connect the power adaptor of the signal transmitter to wall outlets and place the other end to DC output at the back of the transmitter. According to the color coding on the cable, connect RCA cable to Line In. Turn on the power. Select a channel. The signal transmitter is functioning properly when you use the transmitter indicator is lighted.
3. Press the power switch on the system to turn on. You should see the indicator light is on. Select channel on the system to be the same as the one on the signal transmitter. For example, if the system is on Channel 1, transmitter channel should be also on 1. At this time, the system will play the same music as those input to the signal transmitter.

BEAUTY SPEAKER

audio amplifier ⑦

**Setup Instruction:**

4. Adjust volume accordingly. You can also adjust bass level via bass increase control.
5. If the system is used at night, it can be easily identified by the blue light placed on the system.
6. If no transmitter is not in use, other electronic devices can be connected to the system directly via AUX IN. When that happens, signals will not be accepted from the transmitter.
7. The system is equipped with power saving function. When battery is low, the system will assume in the battery save mode. The power indicator light will turn to pink and volume will be turned down automatically. Increasing volume will have no effect until battery is consumed completely.

**FCC Information**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

BEAUTY SPEAKER

audio amplifier ⑧

**FCC Information**

- \* Reorient or relocate the receiving antenna.
- \* Increase the separation between the equipment and receiver.
- \* Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

BEAUTY SPEAKER

WIRELESS OUTDOOR SPEAKER

BT118

audio amplifier

BEAUTY SPEAKER

OPERATION MANUAL

BT118

audio amplifier

FOR LISTENING THIS REPRODUCED NATURAL SOUND IN YOUR LIFE RESPECTFULLY  
WWW.BEAUTYSPEAKER.COM