



## Technical Description

The transmitter of the EUT (Bluetooth Stereo Headset) is powered by 5Vdc from host equipment or Lithium-ion polymer battery or adapter. The antenna is Chip antenna without antenna connector.

This device is a Frequency Hopping device with 79 hopping frequencies.

For more detailed instruction, please take a look at the user's manual.