


Label



“INTERPRETER LR9” water meter label location



Label with FCC ID:VIDLR9INTR and IC:10232A-LR9INTER will be placed here.

The statements according to §15.19(a)(3) and IC requirements are located in User manual, pages 2, 3 (Application exhibit User_manual_36321).