

GUARDIAN

Water Detector

What's included? What's included?




Water Detector-Front



Water Detector-Back view

Sensor to detect temperature



Remote Lead

How to use?

- 1. After installing and configuring your Guardian Valve Controller with the Guardian App, follow instructions on the App to include your Water Detector to the
- 2. Click on "Add new Device" > "set up a new sensor" and enter the pin number located on the back of the Water Detector









How to use?- without the remote lead

You can use the Water Detector to monitor most appliances and pipes for leaks without the remote lead. Once paired with your Guardian Valve Controller, place the Water Detector on a flat surface under the item you want monitored where water will collect if it leaks from above.



Leaking Water Sensor

Water Detector can be made to rest against 3-1/4" base moulding for placement near




How to use?- with the remote lead


Use the remote lead with the Water Detector to detect leaks in hard-to-reach areas. The remote lead plugs into the Water Detector through the 3.5mm mini jack.



Mount the Water Detectoron a metallic surface of an Leak Sensor appliance using the magnets on it's back and place the remote lead in the area you want to montitor.Make sure Remote Lead unthe remote lead is laying flat der the appliance with its metal feet making full contact with the floor or


surface.





How to use?- with the remote lead

To monitor the water level in your sump pump pit, place the Water Detector on a nearby surface and suspend the Remote Lead in the pit 5 inches below the lid. Suspending the Remote Lead in the pit allows you to get a notification before the water starts to overflow the pit. Water Detector



NEED HELP? CONTACT GUARDIAN CUSTOMER SERVICE

If you have questions, our trained Customer Service Department is happy to assist you 24 hours a day, 7 days a week. Contact Guardian Customer Service as follows: • In North America dial: 1-855-249-1754 • Email Guardian at support@ getguardian.com

receiver; connect the equipment into an outlet on a circuit different from that to which DO NOT RETURN THIS PRODUCT TO THE STORE OR WEBSITE FROM WHICH IT the receiver is connected. WAS PURCHASED If you believe the product is defective, has a missing or broken part or are having difficulty with it please contact Guardian by Elexa as listed Consult the dealer or an experienced radio/TV technician for help. The manufacturer above for a guick and efficient solution to the problem.

Legal Notices: This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are undesired operation of the device. designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio fre quency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications.

1 Year Limited Warranty

ElexaConsumerProducts,Inc.("ECP")warrantstotheoriginalretailpurchaser("Purchase However, there is no quarantee that interference will not occur in a particular installa er") that the Guardian (the "Product") will be free of defects in materials or workmans tion. If this equipment does cause harmful interference to radio or television reception, under use for one (1) year from the date of purchase (the "Warranty period"). which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or

For the Purchaser only, if the Product fails to perform as specified during the Warranty Pe riod due to defective parts or faulty workmanship, ECP will repair or replace the defective or damaged parts of the Product. Normal wear and tear is not covered nor is abnorma use, misuse, mishandling, faulty installation, improper shipping, damage caused by disas ters such as fire, flood or earthquake, neglect, accident or tampering. This warranty covers only normal use in the United States or Canada.

To obtain warranty service during the Warranty Period, call Guardian Customer Service (1 is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment. Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil nedoit pas produire de brouillage, et

relocate the receiving antenna; increase the separation between the equipment and the

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le

ECP will repair or replace the defective parts and return them at ECP's cost by a ship ping method selected by ECP. When contacting ECP to obtain an RMA, Purchaser may request expedited return shipping at Purchaser's expense.

its electronic accessories should not be disposed of with other household waste. To

prevent possible harm to the environment or human health from uncontrolled waste

disposal, please separate these items from other types of waste and recycle them

responsibly to promote the sustainable reuse of material resources.

THISWARRANTYISNOTTRANSFERABLE.AND.TOTHEMAXIMUMEXTENTPERMITTED BYAPPI ICABI FLAWISINI IFUOFALI OTHERWARRANTIES REPRESENTATIONS AND CONDITIONS.EXPRESSEDORIMPLIED.STATUTORYOROTHERWISE.INCLUDINGBUT NOTLIMITEDTOTHEIMPLIEDWARRANTIESOFMERCHANTABILITYANDFITNESSFOR APARTICUL ARPURPOSE NOOTHERPERSONORREPRESENTATIVE IS AUTHORIZED TO MAKEANYOTHERWARRANTYONBEHAL FOFECPORASSUMEFORECPANYOTHER

LIABILITYINCONNECTIONWITHTHESALEOFTHISPRODUCT.INNOEVENTWILLECP 855-249-1754) or email: support@getquardian.comforinstructions on sending damaged BELIABLEFORANYDAMAGES.INCLUDINGBUTNOTLIMITEDTOINCIDENTAL.SPECIAL parts and documentation for a Return Material Authorization (RMA). Products returned to ORCONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR IN A BILLITY TO USE THE ECP for repair or replacement without authorization will be returned at the sender's ex PRODUCT.INCLUDINGDAMAGESDUETOECP'SNEGLIGENCE.THISWARRANTYGIVES pense. All warranty claims must be accompanied by a legible copy of the original receipt YOUSPECIFICLEGALRIGHTS.ANDYOUMAYALSOHAVEOTHERRIGHTSWHICHVARY showing date and details of purchase. The RMA number must be clearly written on the FROM STATE TO STATE AND COUNTRY TO COUNTRY. side of the shipping container in which you return the Product or defective parts. Unless otherwise instructed by ECP, the Product must be sent freight pre-paid to the following CORRECT DISPOSAL OF BATTERIES IN THIS PRODUCT This marking on the product, accessories or literature indicates that the product and

Flexa Consumer Products, c/o Promac. 1153 Timber Dr., Elgin, IL 60123

Business users should contact their supplier and check the terms and conditions of the purchasecontract. This product and its electronic accessories should not be mixed with other wastes for disposal.

Household users should contact either the retailer where they purchased this product,

or their government office, for details of where and how they can take these items for

This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66. If batteries are not properly disposed of, these substances can cause harm to human health or the environment

> Model#: GLD1v2 FCC: VII-GLD10002

IC: 22838-GLD10002

©2016 Elexa Consumer Products, Inc. 2275 Half Day Rd., Suite 160 Bannockburn, IL 60015 www.getguardiancom

environmentally safe recycling.



