

RX-80713 Parts list (Power supply control board)						
1	EL217-1000201	Chip Resistor	10 OHM 0603 $\pm 5\%$	3	PCS	R16, R45, R47
2	EL217-1010201	Chip Resistor	100 OHM 0603 $\pm 5\%$	6	PCS	R22, R23, R24, R25, R34, R35
3	EL217-1020201	Chip Resistor	1K OHM 0603 $\pm 5\%$	10	PCS	R2, R3, R5, R7, R9, R11, R18, R30, R33, R43
4	EL217-1030201	Chip Resistor	10K OHM 0603 $\pm 5\%$	9	PCS	R15, R21, R26, R27, R29, R31, R36, R40, R46
5	EL212-9130601	Chip Resistor	91K OHM 0603 $\pm 5\%$	1	PCS	R37
6	EL217-1040201	Chip Resistor	100K OHM 0603 $\pm 5\%$	11	PCS	R1, R4, R6, R8, R10, R12, R17, R19, R28, R32, R38
7	EL217-2040201	Chip Resistor	200K OHM 0603 $\pm 5\%$	1	PCS	R20
8	EL217-2240201	Chip Resistor	220K OHM 0603 $\pm 5\%$	1	PCS	R44
9	EL217-4740101	Chip Resistor	470K OHM 0603 $\pm 5\%$	1	PCS	R41
10	EL217-5140101	Chip Resistor	510K OHM 0603 $\pm 5\%$	1	PCS	R39
11	EL228-05A1101	Chip Capacitor	0.5pF/50V $\pm 0.25P$ 0603	1	PCS	C63
12	EL228-33A1101	Chip Capacitor	3.3pF/50V $\pm 0.25P$ 0603	2	PCS	C61, C64
13	EL228-1001001	Chip Capacitor	10pF/50V $\pm 0.25P$ 0603	1	PCS	C60
14	EL228-1011201	Chip Capacitor	100pF/50V $\pm 5\%$ 0603	3	PCS	C48, C53, C57
15	EL228-4711301	Chip Capacitor	470pF/50V $\pm 10\%$ 0603	1	PCS	C56
16	EL228-1002301	Chip Capacitor	10nF/50V $\pm 10\%$ 0603	1	PCS	C39
17	EL228-01A3401	Chip Capacitor	0.1uF/50V $\pm 20\%$ 0603	27	PCS	C1, C4, C7, C16, C19, C21, C24, C26, C27, C29, C31, C34, C36, C38, C40, C45, C46, C47, C49, C50, C51, C54, C55, C58, C59, C62, C65
18	EL228-0103401	Chip Capacitor	1uF/25V $\pm 20\%$ 0603	8	PCS	C3, C5, C8, C14, C17, C21, C33, C52
19	EL238-3304202	Inductor	333J, 33nH, 0805, $\pm 5\%$	1	PCS	L6
20	EL238-5604201	Inductor	563J, 56nH, 0805, $\pm 5\%$	1	PCS	L5
21	EL274-S805001	audion	S8050, NPN, SOT-23	6	PCS	Q1, Q2, Q3, Q4, Q5, Q6
22	EL273-S855001	audion	S8550, SOT-23	2	PCS	Q8, Q12

23	EL274-S901401	audion	S9014, SOT-23,	1	PCS	Q13
24	EL273-S901201	audion	S9012, SOT-23	3	PCS	Q9, Q10, Q11
25	EL274-S390401	audion	MMBT3904, SOT-23	1	PCS	Q7
26	EL211-1014201	Resistor	100 OHM 1/2W ±5%	1	PCS	R14
27	EL231-22A3201	Inductor	2. 2uH,0307,±5%	4	PCS	L1, L2, L3, L4
28	EL323-4352001	Resonator	435.2MHz 20pF, ±30ppm, T0-39	1	PCS	X1
29	EL265-A414804	Diode	LA4148	3	PCS	D9, D11, D12
30	EL262-N400701	Diode	1N4007, DO-41	2	PCS	D8, D10
31	EL268-N400103	Diode	1N4001, DO-214AC	6	PCS	D1, D2, D3, D4, D5, D6
32	EL262-FR30201	Diode	FR302, DO-27	1	PCS	D7
33	EL39B-HA00011	buzzer	THDZ-12095, Φ12*7 .5 3.3V	1	PCS	BL1
34	EL222-4713406	Capacitor	470uF/10V ±20%, Ø6 x 12	3	PCS	C30, C32, C35, C37
35	EL222-2213411	Capacitor	220uF/25V ±20%, Ø6 x 12	2	PCS	C25
36	EL222-1023407	Capacitor	1000uF/25V ±20%, Ø10 x 17	2	PCS	C22, C23
37	EL351-16A3001	fuse	30V U160 1.6A : 5mm	1	PCS	F1
38	EL241-P753601	IC	IC PJ7536-3.6V T0-92 18V	1	PCS	U1
39	EL22E-01A3301	high-voltage capacitor	0.1uF/500V(Y2) ±10%	4	PCS	C10, C11, C12, C13
40	EL242-8071301	Integrated circuit	P07, YMD004_P07_FICF, SOP-28	1	PCS	U3
41	EL242-C24C021	Integrated circuit	CSI24C02WI SOP-8	1	PCS	U2
42	EL242-4316001	Integrated circuit	PT4316 SOP-16	1	PCS	U4
43	EL301-2P00005	Socket	2P, 3.96mm	4	PCS	CON1, CON2, CON3, CON4
44	EL301-4P00001	Socket	4P, 2.54mm	1	PCS	CON5
45	EL301-5P00001	Socket	5P, 2.54mm	2	PCS	CON6, CON7
46	EL213-22B7201	Resistor	0.22Ω /5W±5%, 14mm、18mm、5mm	1	PCS	R13
47	EL361-J000011	Relay	CLIN T73 , DC12V , 10A	6	PCS	SK1, SK2, SK3, SK4, SK5, SK6

1	EL265-MH28101	switch	MH281 SOT-23	3	PCS	VK1, VK2, VK3
2	EL301-5P00001	socket	5P, 2.54mm	1	PCS	CON1
3	EL228-01A3401	Capacitor	0.1uF/50V ±5% 0603	1	PCS	C1
RX-80713-F. B. D						
1	EL265-MH28101	Switch	MH281 SOT-23	2	PCS	VK1, VK2
2	EL301-4P00001	Socket	4P, 2.54mm	1	PCS	CON1
3	EL228-01A3401	Capacitor	0.1uF/50V ±5% 0603	2	PCS	C1, C2
RX-80713-U-H-D						
1	EL265-MH28102	Switch	MH281 TO-92	3	PCS	VK1, VK2, VK3
2	EL301-5P00001	Socket	5P, 2.54mm	1	PCS	CON1
3	EL228-01A3401	Capacitor	0.1uF/50V ±5% 0603	1	PCS	C1