

TX-80713 Parts List (Remote board)						
1	EL217-0000201	Chip Resistor	0R OHM ,±5% ,0603	1	PCS	R14
2	EL217-1010201	Chip Resistor	100R OHM ,±5%, 0603	4	PCS	R12, R18, R19, R20
3	EL217-1020201	Chip Resistor	1K OHM, ±5% ,0603	4	PCS	R2, R3, R15, R16
4	EL217-1030201	Chip Resistor	10K OHM ,±5%, 0603	2	PCS	R9, R21
5	EL217-3030201	Chip Resistor	30K OHM, ±5%, 0603	6	PCS	R5, R6, R7, R8, R10, R11
6	EL217-4730201	Chip Resistor	47K OHM ,±5% ,0603	1	PCS	R1
7	EL217-4740201	Chip Resistor	470K OHM ,±5%, 0603	1	PCS	R13
8	EL217-1050201	Chip Resistor	1M OHM ,±5%, 0603	1	PCS	R4
9	EL228-0101101	Chip Capacitor	1pF/50V , ±0.25P, 0603	1	PCS	L2
10	EL228-0201101	Chip Capacitor	2pF/50V ,±0.25P , 0603	1	PCS	L3
11	EL228-0301101	Chip Capacitor	3pF/50V ,±0.25P , 0603	2	PCS	C13, C22
12	EL228-39A1101	Chip Capacitor	3.9pF/50V , ±0.25P , 0603	4	PCS	C17, C19, C20, C21
13	EL228-82A1101	Chip Capacitor	8.2pF/50V , ±0.25P , 0603	2	PCS	C16, C18
14	EL228-1011201	Chip Capacitor	100pF/50V ,±5%P, 0603	1	PCS	C15
15	EL228-2211301	Chip Capacitor	220pF/50V , ±10%P , 0603	1	PCS	C7
16	EL228-0102301	Chip Capacitor	1nF/50V , ±10%P, 0603	1	PCS	C12
17	EL228-01A3401	Chip Capacitor	0.1uF/50V,±20% , 0603	6	PCS	C1, C2, C3, C4, C5, C10
18	EL274-BR95101	audion	NPN, MAR951,,SOT-23	1	PCS	Q3
19	EL274-S901801	audion	SOT-23	1	PCS	Q2
20	EL273-S855001	audion	SOT-23,	1	PCS	Q1
21	EL237-68A4201	Inductor	682J, 6. 8nH, ±5% , 0603	3	PCS	L5, L6, L7
22	EL237-1014201	Inductor	104J, 100nH, ±5% , 0603	2	PCS	L4, L8
23	EL237-1514201	Inductor	154J, 150nH, ±5% , 0603	1	PCS	L1
24	EL323-4339201	Resonator	433.92MHz TO-93 ,20pF, ±30ppm	1	PCS	X1
25	EL242-P445001	Integrated Circuit	IC PT4450, SOT-23-6	1	PCS	U2

26	EL242-8071202	Integrated Circuit		1	PCS	U1
27	EL222-1003411	Capacitor	10uF/16V ±20% 4*5	2	PCS	C6, C11
28	EL331-TS00033	key-press	6*6*8 (4P)	6	PCS	SW1, SW2, SW3, SW4, SW5, SW6
29	EL261-0300006	luminotron	Φ3, 3AB4SF01, (640) nm	1	PCS	LED1
30	EL261-0100004	luminotron	Φ3, 3AR4HD01 , (645) nm	1	PCS	LED2