



1. A cable with an Amphénol C16-1female connector:
 - Transponder power supply.
 - RS232 serial interface.
2. A cable with an Amphénol C16-1male connector:
 - RS485 serial interface.
3. A N plug is used to connect the VHF antenna.
4. A ground terminal is used to connect the transponder to the ground of the buoy.
5. A tricolor LED is used to monitor the transponder.