

Product registration
Thank you for purchasing an 808 product. We pride ourselves on the quality and reliability of all our electronic products, but if you ever need service or have a question our customer service staff stands ready to help. Contact us at www.808audio.com. **PURCHASE REGISTRATION:** Registering Online will allow us to contact you in the unlikely event a safety notification is required under the Federal Consumer Safety Act. **Register Online at: www.808audio.com. Click on Product Registration and Fill Out the Brief Questionnaire.**

Enregistregistro del productoremplido du produit
Merci d'avoir acheté un produit 808. Nos enorgulles de la qualité y fiabilidad de todos nuestros productos electrónicos, pero si alguna vez necesita servicios técnicos o si tiene alguna pregunta nuestro personal de atención al cliente está a su disposición para ayudarle. Comuníquese con nosotros en www.808audio.com. **REGISTRO DE COMPRA:** El registro en línea nos permitirá comunicarnos con usted en el caso de tener que enviarse algún aviso de seguridad en virtud de la Ley Federal de Seguridad del Consumidor. **Registre el producto en línea en: www.808audio.com. Haga clic en Registro del producto y responda al cuestionario.**

Enregistrement du produit
Merci d'avoir acheté un produit 808. Nous sommes fiers de la qualité et de la fiabilité de tous nos produits électroniques, mais en cas de nécessité de réparation ou pour toute question le personnel de notre service clientèle est prêt à vous aider. Contactez-nous sur www.808audio.com. **ENREGISTREMENT DU PRODUIT:** L'enregistrement en ligne nous permettra de communiquer avec vous pour tout avis de sécurité en vertu du Federal Consumer Safety Act (Loi fédérale de protection du consommateur). **Enregistrez votre produit en ligne sur: www.808audio.com. Cliquez sur Enregistrement produit et remplissez le court questionnaire.**

EN/EF
It is important to read this user manual prior to using your new product for the first time.
Es importante leer este manual antes de usar por vez primera su equipo.
Nous vous recommandons de lire ce manuel d'instructions avant d'utiliser votre nouveau produit pour la première fois.

FCC/Industry of Canada Information

Note: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular

installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:



- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by VOXX Accessories Corporation could void the user's authority to operate the equipment.

RF Exposure Warning
This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

This device complies with Industry of Canada licence-exempt standard RSS 210
Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

user manual guide de l'utilisateur manual de usuario



WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

Some of the following information may not apply to your particular product; however, as with any electronic product, precautions should be observed during handling and use.

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings.


Install in accordance with the manufacturer's instructions.

- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

IMPORTANT SAFETY INFORMATION

- The AC adapter supplied with this product is intended to be correctly oriented in a vertical or floor mount position.
- Do not use unauthorized chargers or power adapters. Use only chargers that came with your product or that is listed in the user's guide.
- Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
- Always leave sufficient space around the product for ventilation. Do not place product in or on a bed, rug, in a bookcase or cabinet that may prevent air flow through vent openings.
- Do not place lighted candles, cigarettes, cigars, etc. on the product.
- Care should be taken so that objects do not fall into the product.
- Do not attempt to disassemble the cabinet. This product does not contain customer serviceable components.
- The following information is located at the bottom of apparatus.
- The equipment shall not be exposed to dripping or splashing or placed near objects filled with liquids.
- To be completely disconnected the power input, the AC adapter of apparatus shall be disconnected from the mains.

Tour of the speaker



(1) Pair button
Pair puts the speaker in pairing mode for Bluetooth setup (press and hold for 3 seconds). It also performs a fast reconnection with devices that have lost connection (press and release). See the Bluetooth setup section for more information.

(2) Volume +/- buttons
Volume +/- buttons adjust the speaker's volume level.

(3) On button
On turns the speaker on and off.

(4) Power and Pairing indicator
shows the status of the speaker. **Blue, slow blinking:** The speaker is on but not paired or connected. **Blue, fast blinking:** The speaker is in Bluetooth pairing mode. See the Bluetooth Setup section for more information.

Introduction


The SP900 portable wireless speaker makes it easy to take your music wherever you go and share it whenever you want, with Bluetooth® wireless connectivity and a built-in auxiliary input. It's compact, easy-to-carry and simple to use.

This manual covers various connection options and detailed operating instructions for making the customizable portable wireless speaker a part of your lifestyle. If, after having reviewed the instructions, you have any questions, please call toll-free at 1-800-732-6866 or visit www.808audio.com.

Using the Auxiliary Audio Input

Making a Direct Connection

- If the speaker isn't already on, press the On button to turn it on.
- Connect one end of the provided 3.5mm audio in cable to the AUX IN jack on the back of the speaker.
- Connect the other end of the cable to the headphone output on your MP3 player or other portable audio device.



Warning: This product is designed to work with line level outputs only. **DO NOT** connect it directly to speaker outputs as it will permanently damage the speaker.

Press the On button on the top of the speaker to turn the speaker off. Confirm that the speaker is off by verifying that the indicator light on the top of the speaker is no longer illuminated.

Note: When using AUX IN mode make sure the Bluetooth on a paired device is turned off.

- Check that the AC power adapter is fully inserted into the wall outlet and the power cord from the AC adapter is firmly connected to the speaker's power input jack.
- If you're using batteries for the speaker, check that they are fresh and inserted with correct polarity (+, -). Make sure the batteries are

Troubleshooting

The following troubleshooting guide takes you through some of the more common problems associated with the installation and/or operation of a wireless system. If the problem persists, please call toll-free at 1-800-732-6866 or visit www.808audio.com.

fresh and replace if necessary.

- Confirm that the speaker is turned on.
- Check that the audio source component (stereo, MP3 player, etc.) is turned on and transmitting sound as it normally should.
- Make sure the volume on your audio source is turned up.
- Check that the speaker volume is turned up.
- Move the Bluetooth device and the speaker closer together. The Bluetooth wireless technology generally can operate within a range of 33 feet. However results may vary based on other factors such as room layout, wall material, weather conditions, etc.
- Make sure you entered the correct passkey when pairing your device.

Cannot pair the speaker with your Bluetooth device

IMPORTANT INSTRUCCIONES DE SEGURIDAD

FAVOR DE GUARDAR ESTO PARA UNA REFERENCIA FUTURA

como periódicos, paños, cortinas, etc.


- Ninguna fuente de flama abierta, tal como velas encendidas, deberá colocarse sobre el aparato.
- Se deberá poner atención a los aspectos ambientales al eliminar las baterías.
- Para EQUIPO QUE REQUIERA CONEXIÓN, la toma de corriente deberá instalarse cerca del equipo y deberá ser de fácil acceso.
- No se deberá exponer el aparato a goteo o salpicaduras ni colocarlo cerca de objetos que contengan líquidos.
- Precauciones importantes para la batería
- Cualquier batería puede presentar un riesgo de fuego, explosión o quemadura química si es mal tratada. No tente de cargar una batería que no esté diseñada para

Introducción

La bocina inalámbrica portátil SP900 le facilita llevar su música a donde vaya y compartirla cuando quiera, con conectividad Bluetooth® inalámbrica y entrada auxiliar incorporada. Es compacta, fácil de llevar y simple de usar.

Este manual cubre varias opciones de conexión e instrucciones detalladas de operación para hacer de la bocina inalámbrica portátil una parte de su estilo de vida. Si, después de haber revisado las instrucciones, usted tiene una pregunta, por favor llame sin cargo al teléfono 1-800-732-6866 o visite www.808audio.com.

Tour de la bocina



(1) Botón Asociar
Pair coloca la bocina en modo asociar para configuración Bluetooth (presione y mantenga presionado por 3 segundos). Este realiza también una reconexión rápida con dispositivos que han perdido la conexión (presione y libere). Para más información vea la sección de configuración Bluetooth.

(2) Botones de volumen +/-
Los botones Volume +/- ajustan el nivel de volumen de la bocina.

(3) Botón On
On enciende y apaga la bocina.

(4) Indicador de Encendido y Asociación muestra el estatus de la bocina.
Azul, parpadeando lento: la bocina está encendida pero no está asociada o conectada. **Azul, parpadeando rápido:** la bocina está en modo asociarse Bluetooth. Vea

Powering the Speaker System

Important battery precautions

- Any battery may present a risk of fire, explosion, or chemical burn if abused. Do not try to charge a battery that is not intended to be recharged, do not incinerate, and do not puncture.
- Non-rechargeable batteries, such as alkaline batteries, may leak if left in your product for a long period of time. Remove the batteries from the product if you are not going to use it for a month or more.
- If your product uses more than one battery, do not mix types and make sure they are inserted correctly. Mixing types or inserting incorrectly may cause them to leak.
- Discard any leaky or deformed battery immediately. They may cause skin burns or other personal injury.
- Please help to protect the environment by recycling or

disposing of batteries according to federal, state, and local regulations.

- WARNING:** The battery (battery or batteries or battery pack) shall not be exposed to excessive heat such as sunshine, fire or the like.

Ecology
Help protect the environment - we recommend that you dispose of used batteries by putting them into specially designed receptacles.

Precautions for the unit

- Do not use the unit immediately after transportation from a cold place to a warm place; condensation problems may result.
- Do not store the unit near fire, places with high temperature or in direct sunlight. Exposure to direct sunlight or extreme heat (such as

inside a parked car) may cause damage or malfunction.


- Clean the unit with a soft cloth or a damp chamois leather. Never use solvents.
- The unit must only be opened by qualified personnel.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by VOXX Accessories Corporation is under license. Other trademarks and trade names are those of their respective owners.

Powering the Speaker

There are two options to power your wireless speaker: using the included AC power adapter or using 8 AA batteries (not included).

AC Power Adapter



(5) AUX IN
AUX IN connects directly to your MP3 player, smartphone, or other portable audio device, using the 3.5mm audio in cable provided.

(6) DC In
DC In receives the small round end of the included 12V DC 1000mA AC power adapter; remove the protective cover to insert the adapter.

(7) Battery Compartment Cover
Remove to install 8 AA batteries.

Notes:

- Be sure to use the speaker AC power adapter rated 12V DC 1000 mA.
- The power unit should be plugged in so that it stays vertical or lies flat.

Specifications

Speaker

- Bluetooth® wireless technology:
- Bluetooth v4.0
- Profile: A2DP audio sink, AVRCP
- Class 2 Radio
- 2-way acoustic design:
- 2.5" driver, 1.5" tweeter
- Passive Radiator: 2.5" x 3" oval
- Audio line-in
- Operation distance : Up to 33 Feet (open area)
- Frequency response: 20Hz - 20kHz
- Operates using supplied AC adapter
- or eight (8) AA batteries (not included)

*Maximum range; results may vary according to environment.

12 Month Limited Warranty

VOXX Accessories Corporation (the "Company") warrants to the original retail purchaser of this product that should this product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 12 months from the date of original purchase, such defects will be repaired or replaced (at the Company's option) without charge for parts and repair labor. To obtain repair or replacement within the terms of this Warranty, the product along with any accessories included in the original packaging is to be delivered with proof of warranty coverage (e.g. dated bill of sale), identification of defect(s), transportation prepaid, to the Company at the address shown below. Do not return this product to the Retailer.

This Warranty is not transferable and does not cover product purchased, serviced or used outside the United States or Canada. The warranty does not

Setting Up Bluetooth Wireless

Pairing
The Bluetooth-enabled device that you wish to stream audio to your speaker system must first be paired to the speaker. The process is simple, and in most cases the pairing process needs to be done only once.

To pair your Bluetooth-enabled device with the speaker:

- Make sure your device's Bluetooth is turned on. See the wireless and/or network settings menu on your device to check.
- If the speaker isn't already on, press the On button to turn it on. You will hear the turn on music to indicate the speaker is turned on. The indicator light on the top of the speaker starts flashing blue.
- Open the Bluetooth settings menu on your device. Select "808 Hex TL" from the list of devices available (you might have to scan for devices).

If your device asks for a password, enter "0000".

- A confirmation screen will appear on your device once the speaker and the device are successfully paired. The blue indicator turns solid blue to indicate successful connection. The speaker is now ready for you to stream audio from your device.
- Turn the volume on your device to at least 3/4 max, then start playing something on the device. Control the speaker volume on the speaker itself, using the Volume +/- buttons on the top of the speaker.

Note: If you notice the sound from the speaker is distorted, turn down your device's volume.

Reconnecting
When you turn it on, the SP900 reconnects automatically with the last paired device. When you leave the Bluetooth operating range, with the SP900 turned ON, it disconnects. When you come back into the Bluetooth operating range, press the Pair button to reconnect to the last paired device. The successfully paired music will sound once it has been successfully repaired.

Streaming Audio With Bluetooth
Once you've paired and connected your device with the speaker, you can control music playback from the palm of your hand. Select your music, stop it, change songs and playlists, all right from your device's screen.

To adjust volume: Press the Volume +/- buttons on top of the speaker.

Español

damage so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state/province to state/province.

U.S.A.: Audiovox Return Center, 150 Marcus Blvd., Hauppauge, New York 11788

CANADA: Audiovox Return Center, c/o Genco, 6685 Kennedy Road, Unit #3 Door 14, Mississauga Ontario L5T 3A5

Alguna de la siguiente información quizá no se aplique a su producto en particular. Sin embargo, como con cualquier producto electrónico, se deben tomar precauciones durante su manejo y uso.

- Lea estas instrucciones.
- Conservé estas instrucciones.
- Tome en cuenta todas las advertencias.
- Siga todas las instrucciones.
- No use este aparato cerca del agua.

utiliza un carro, tenga precaución al mover la combinación de control aparato para evitar lesión ocasionada por volcadura.

- Desconecte este aparato durante tormentas eléctricas o cuando no sea utilizado por largos periodos de tiempo.
- Refiera todo el servicio a personal de servicio calificado. El servicio es requerido cuando el aparato ha sido dañado de alguna forma, tal como daño a la clavija o al cable de corriente, cuando se ha derramado líquido o han caído objetos dentro del aparato, el aparato ha sido expuesto a lluvia o humedad, no funciona normalmente, o ha sido tirado.

INFORMACION ADICIONAL DE SEGURIDAD

- El adaptador CA suministrado con este producto está diseñado para

estar orientado correctamente en la posición de montaje vertical o en el piso.

- No use cargadores o adaptadores de corriente no autorizados. Sólo utilice cargadores o adaptadores de corriente que vengan con su producto o que estén listados en la guía del usuario.
- El aparato no debe quedar expuesto de goteo o salpicaduras de líquidos, y, por lo tanto, no se deben colocar sobre el aparato objetos que contengan líquidos, como por ejemplo vasos.
- Siempre deje suficiente espacio para ventilación alrededor del producto.
- No ponga velas, cigarrillos o cigarreros encendidos encima de producto.

Información de la industria de Canadá/FCC

Note: Este aparato obedece las especificaciones de la Parte 15 de las regulaciones FCC. Las funciones están sujetas a las siguientes condiciones: 1) Este aparato no puede causar interferencias dañinas, y 2) este aparato puede recibir cualquier interferencia, incluyendo aquellas que puedan causar funciones no deseadas.

Este equipo produce una interferencia perjudicial con la recepción de la radio o la televisión, lo cual podría determinarse apagando y encendiendo el equipo, se le pide al usuario que intente corregir la interferencia siguiendo una o varias de las siguientes medidas.

- Reorienta o reubique la antena receptora.
- Aumente la separación entre el equipo y el receptor
- Conecte el equipo a un toma corriente diferente al que conecta el receptor
- Consulte al distribuidor o a un técnico especializado en radio / TV para solicitar ayuda

comunicaciones de radio. Sin embargo, no existe ninguna garantía de que no se vaya a producir una interferencia en una instalación particular. Si este equipo produce una interferencia perjudicial con la recepción de la radio o la televisión, lo cual podría determinarse apagando y encendiendo el equipo, se le pide al usuario que intente corregir la interferencia siguiendo una o varias de las siguientes medidas.

VOXX Accessories Corporation podrían invalidar la autoridad del usuario para hacer funcionar el aparato.

Advertencia de Exposición RF
Este equipo debe ser instalado y operado de conformidad con las instrucciones suministradas y la(s) antena(s) usada(s) para el transmisor debe(n) instalarse para disponer de una distancia de separación de al menos 20 cm. de todas las personas y no debe estar, ubicada u operando en conjunto con alguna otra antena o transmisor. Se debe proporcionar a los usuarios finales e instaladores instrucciones de instalación de antena y condiciones de operación del transmisor para satisfacer el cumplimiento con la exposición a RF.

Este dispositivo cumple con las normas RSS 210 de Industria Canadá de las unidades exentas de licencia.

La operación está sujeta a las dos condiciones siguientes: 1) este dispositivo puede no causar interferencia y 2) este dispositivo debe aceptar cualquier interferencia, incluyendo interferencia que pueda causar una operación no deseada del dispositivo.

Declaración de Exposición a Radiación IC:
Este equipo cumple con los límites de exposición a la radiación IC establecidos para un entorno no controlado.


Información Regulatoria de la Industria Canadiense
CAN ICES-3 (B)/NMB-3 (B)

Introducción

Este manual cubre varias opciones de conexión e instrucciones detalladas de operación para hacer de la bocina inalámbrica portátil una parte de su estilo de vida. Si, después de haber revisado las instrucciones, usted tiene una pregunta, por favor llame sin cargo al teléfono 1-800-732-6866 o visite www.808audio.com.

Este manual cubre varias opciones de conexión e instrucciones detalladas de operación para hacer de la bocina inalámbrica portátil una parte de su estilo de vida. Si, después de haber revisado las instrucciones, usted tiene una pregunta, por favor llame sin cargo al teléfono 1-800-732-6866 o visite www.808audio.com.

Tour of the speaker



(1) Botón Asociar
Pair coloca la bocina en modo asociar para configuración Bluetooth (presione y mantenga presionado por 3 segundos). Este realiza también una reconexión rápida con dispositivos que han perdido la conexión (presione y libere). Para más información vea la sección de configuración Bluetooth.

(2) Botones de volumen +/-
Los botones Volume +/- ajustan el nivel de volumen de la bocina.

(3) Botón On
On enciende y apaga la bocina.

(4) Indicador de Encendido y Asociación muestra el estatus de la bocina.
Azul, parpadeando lento: la bocina está encendida pero no está asociada o conectada. **Azul, parpadeando rápido:** la bocina está en modo asociarse Bluetooth. Vea

Notas:

- Asegúrese de usar el adaptador de corriente CA con clasificación 12V DC 1000 mA.
- La unidad de poder deberá ser conectada de manera que ésta permanezca vertical u horizontal.

