



id221 idChat W1 App Remote Control User Manual

Installation

Installing Remote Control



Changing Battery




Pairing APP

1 Installing APP




Search and download "idChat" on Google Play or App Store and install "idChat" into your mobile phones.

2 Register An Account




Open "idChat" App and click "Register" to go to the register page. Complete the register form and press "Send" to get the verification code. The verification code will be sent to your mobile number by SMS. Get the verification code from your phone and fill in the verification box. Read and accept the "idChat Terms of Service" and press "Register".


3 Pairing W1 Remote Control



Press "+" on the "Chat" page and select "My Smart Devices" or Press "🔍" to search Bluetooth devices. At the same time, press the button on the W1 remote Control to enter into pairing mode.




Select the item with the same serial number at the back of the W1 remote control.



It will show "connected" if the device is paired.

Tap "🗑️" to disconnect device or forget device.



If idChat cannot find the W1 Remote Control, please press the "🔍" to start searching again.

Once idChat connects to the W1 remote control, the "🔍" at the top-left corner on "Chat" page will turn to blue.

Setting Multi-User Intercom


Adding Contacts



Open "Chat Page", Press "Add Contacts", enter nick name or phone number to add contacts.


Note: If a contacts in your phone is using idChat as well, idChat will automatically add her/him as your idChat contact.

Creating Groups



Tap the "+" menu on "Chat" page and select "Create Group"


Select your contacts to join the group and press "✓" at the top-right corner to create group.



Press "👤" and "Profile" to open profile page.


You can edit the group name and profile on this page.

Initializing Multi-User Intercom




Tap "🗨️" at the top-right corner to activate and deactivate multi-user intercom. The "🗨️" will turn to blue when multi-user intercom is activated. You are in the standby mode when multi-user intercom is activated. You can hear the conversation but cannot talk to the group in the standby mode.

Switching Between Talk Mode and Standby Mode



Press the W1 remote control to turn the multi-user intercom from standby mode to talk mode. You can press "+" menu and select "Recording Setting" to choose the button configuration; "Long Press Recording" or "Switch Recording". If "Long Press Recording" is selected, you have to press and hold the remote control for the whole recording period. When you release the W1 button, it will terminate the talk mode and turn to standby mode. If "Switch Recording" is selected, you can short press the remote control to initiate the talk mode. You don't have to hold the W1 button in the talking period. When you finish your recording, press the W1 button again to terminate the talk mode and turn to standby mode.

Quick Setup



Press and hold groups or contacts on "Chat" page to activate the multi-user intercom.

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning:

Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.