
MBP18 - Quick Start Guide

For a full explanation of all features and instructions, please refer to the User's Guide.

1 Setting up your digital baby monitor



2 Basic operation of the keys

Parent unit		
٣	ON/OFF button	Press and hold to turn the unit ON/OFF.
▲ ■+	UP/VOL+ buttons	Press to increase sound volume. Press to adjust menu up setting.
₫ - ▼	DOWN/VOL- buttons	Press to decrease sound volume. Press to adjust menu down setting.
• ≡ ок	MENU/OK button	Press to open menu options or exit. Press to confirm a selection. Press to pan right in 2x zoom level.
9	Return/Switch Camera button	Press to return to previous menu level. Press to switch camera units. (if paired with more than one camera) Press to pan left in 2x zoom mode.
Ŷ	VIDEO button	Press to turn the LCD display ON/OFF.
Ð,	ZOOM button	Press once to switch to 2x zoom level. Toggle again to return to normal view (1x).
Baby unit		
ON/OFF switch		Push power switch to the right to switch on the unit. Push power switch to the left to switch off the unit.

3 General Information

If your product is not working properly...

- 1. Read this Quick Start Guide or the User's Guide.
- 2. Visit our website: www.motorola.com
- 3. Contact Customer Service:

US and Canada 1-888-331-3383



Manufactured, distributed or sold by Binatone Electronics International LTD., official licensee for this product. MOTOROLA and the Stylized M Logo, are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. and are used under license. All other trademarks are the property of their respective owners.

© 2012 Motorola Mobility LLC. All rights reserved.

Printed in China Version 1.0

