



motorola

MODEL: SONIC SUB 500

Frequency Band: 2.402 -2.480 GHz


Maximum RF Power: 4dBm

Working temperature: -10oC -45 oC

Product ID: SP025


FCC ID: VLJ-SP025

IC: 4522A-SP025




Quick Start Guide / Guía de inicio rápido / Snelstartgids / Guia de Inicio Rápido / Guida per il primo utilizzo / Schnellstartanleitung / Guide de démarrage rapide / Snabbstartsguide / Poradnik użytkownika / 快速入門指南 / 快速入門指南 / Краткое руководство пользователя / دليل التشغيل السريع / Hızlı Başlangıç Kılavuzu / クイックスタートガイド / 빠른 시작 안내서 / คู่มือเริ่มต้นใช้งาน / Коротке керівництво користувача

## ① key feature



## ② basic operation



## EN

### Power on/ off

- press and hold button 3S to turn ON/OFF and select "Sonic Sub 500" from phone menu.
- double-click to enter 2 speaker link mode.

### Volume up

- short Press to increase volume;
- press and hold for 2s to play the next track.

### play/pause /BT disconnect

- short Press to play /Pause,
- Press and hold for 2s to connect /disconnect Bluetooth
- double press can start to "Voice Assistant"

### Volume down

- short Press to decrease volume; press and hold it for 2s to play the last track.

### Wireless Chargepad

- When Sonic SUB 500 is power on, or in charging with power supply, put your phone on the product (center the phone with the wireless charging symbol on the product), can charge your device.

### Type C input

- Type C input for power supply, standard input power is 5V 2A

### Single Speaker BT Connection Process

- Power on only one speaker. The blue LED will flash when power is on. Wait until you hear the "Pairing" from the speaker. Select the model of Sonic Sub you have from the BT menu to and pair the speaker to your mobile device. You will hear "Pairing complete" when the speaker is connected.

### Two Speaker Linking Process

- Power on both speakers to put them into pairing mode. Double click the power button on either speaker to enter link mode. You will hear "Left Channel, Right Channel".
- Go to the BT menu on your device and select the model of Sonic Sub 500 that you have, you will hear "Pairing complete" when the speaker is connected
- If you previously connected one speaker to your phone, power on the other speaker and after you hear "Pairing" double click the power button to enter link mode. "You will hear Left Channel, Right Channel"

size: 75 x 200mm

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.