

# EX1PS3

## BLUETOOTH HEADSET FOR PS3™

Thank you for purchasing the EX1PS3 Bluetooth Headset from Gioteck.

We hope that this product will go beyond your expectations for a quality made accessory.

Please read this booklet thoroughly before using the product and review the PS3™ manual for additional details regarding PS3™ operation.


Thank you & enjoy!

### PRECAUTIONS


This product has been designed with the highest concern for safety. However, any electrical device, if used improperly, has the potential to cause harm. To help ensure risk-free operation please pay attention to the following guidelines.


- Use only as intended. This is a precision product, handle with care.
- Contains small parts. Not suitable for children under 3 years of age.
- Store in a dry & dust free area.
- Do not store in areas of extreme heat or cold, and avoid direct sunlight or heat sources eg. heaters.
- Do not allow the product to get wet or dirty; doing so may cause damage.
- Do not clean with benzene, paint thinner, acetone, alcohol, or other such solvents.
- Do not take the product apart; doing so will void your warranty and may cause electrical shock.

### WARNINGS

 This symbol indicates important installation, operational or maintenance instructions. Always follow these instructions closely.

### ENVIRONMENT

 Please help to conserve the environment by recycling the cardboard packaging of this product.

 This product should NOT be disposed of in normal household waste. It should be disposed of separately. Please take it to an electrical waste collection point.

### LEGALS

This product complies with the following legal regulations. For further information go to [www.gioteck.com](http://www.gioteck.com)

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a


Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

 Gioteck hereby declares that this product is in compliance with the essential requirements and other provisions of Directive 2004/108/EC. To view the full version of the Declaration of Conformity please go online to [doc.gioteck.com](http://doc.gioteck.com)

 N13179

**TROUBLESHOOTING TIPS & TO VIEW THIS MANUAL ONLINE:**  
[WWW.GIOTECK.COM](http://WWW.GIOTECK.COM)

# EX1PS3


## BLUETOOTH® HEADSET FOR PS3™

### FEATURES & DETAILS

The EX1PS3 Bluetooth® Headset has been exclusively designed for gamers and gaming. So you can now maximise your game time without an irritating, uncomfortable earpiece, and still hear your opponent creeping up behind you on your surround sound system!

### GB

- 01 | Microphone
- 02 | Speaker
- 03 | Earhook
- 04 | LED Feedback
- 05 | Volume Decrease
- 06 | Power / Mute / Reconnect
- 07 | Volume Increase



### FR

- 01 | Microphone
- 02 | Haut-parleur
- 03 | Oreillette
- 04 | DEL de Retour
- 05 | Baisse du Volume
- 06 | Alimentation / Silencieux / Reconnexion
- 07 | Hausse du Volume

### ES

- 01 | Micrófono
- 02 | Altavoz
- 03 | Gancho
- 04 | Indicador LED
- 05 | Reducir volumen
- 06 | Encendido / Silencio / Reconectar
- 07 | Aumentar volumen

### PT

- 01 | Microfone
- 02 | Altifalante
- 03 | Gancho para a orelha
- 04 | LED de Feedback
- 05 | Diminuição de volume
- 06 | Energia / Silencioso / Ligar de novo
- 07 | Aumento de volume

### DE

- 01 | Mikrofon
- 02 | Lautsprecher
- 03 | Ohrbügel
- 04 | LED-Rückmeldung
- 05 | Lautstärke verringern
- 06 | Betriebstaste/Stumm/Wieder verbinden
- 07 | Lautstärke erhöhen

### IT

- 01 | Microfono
- 02 | Altoparlante
- 03 | Gancio
- 04 | Stato del LED
- 05 | Riduzione del volume
- 06 | Accensione / Disattivazione / Ricollegamento
- 07 | Aumento del volume



### CZ



- 01 | Mikrofon
- 02 | Reproduktor
- 03 | Spona
- 04 | Kontrolka LED
- 05 | Snížení hlasitosti
- 06 | Napájení / Ztlumení / Nové připojení
- 07 | Zvýšení hlasitosti

### 1. CHARGING YOUR HEADSET

Prior to using the headset for the first time, it is strongly recommended to fully charge the battery for 3 hours.


- 1) Connect the USB cable to your PS3 and the mini usb into the headset's charging socket.
- 2) The LED will illuminate green during charging and will be off when fully charged. Note: Charging indication will be delayed for a few minutes if the headset has not been used for a long time. Normally the battery is fully recharged within 3 hours.
- 3) As soon as the battery is fully charged, the LED will be off / weak Green.
- 4) Disconnect the USB cable from the PS3 and the headset. The fully charged battery offers up to 6 hours use.



-  It is advisable to always recharge after lengthy gameplay.
-  Do not try to pair the headset to the console when the headset is charging. It will not pair to the PS3 if it is charging.


### 3. PAIRING


- 1) PS3 > Settings > Accessory Settings > Manage Bluetooth® Device > Yes
- 2) Prepare your headset (from off) to be paired by holding down the power button continuously until the LEDs flash alternate Blue & Green.
- 3) Start Scanning > PS3EX1PS3 > Enter 0000 (four zeros) > OK > Register Completed
- 4) Press circle button x2 > Accessory Settings > Audio Device Settings > Input Device: PS3 EX1PS3 > Output Device: PS3 EX1PS3 > OK
- 5) Your EX1PS3 is now ready to use.



### 2. OPERATION

- 1) To power on your headset, press and hold the power button for 4 seconds until the LED flashes Blue. Note: If the LED flashes Green only, the battery will need to be charged.
- 2) To fit your headset comfortably, flex the earhook and loop it around your ear. Position the speaker inside your ear for optimal audio performance.
- 3) To power off your headset, press and hold the power button for 4 seconds until the LED flashes Green.

-  To reconnect the headset to your PS3 at any time, press the power button.



### 4. ADJUSTING VOLUME

Tap the + button to increase the volume in increments until the headset reaches your desired volume level.

Tap the - button to decrease the volume in increments until the headset reaches your desired volume level.

### 5. MUTING

Press the power button briefly (less than 1 second) to mute the headset; repeat the process to un-mute.

