

Boom mic Headset with Wireless PTT



Your package should include the following:

- 1) a boom mic headset
- 2) a wireless PTT

Wireless PTT

1. You should check that the serial number on the Wireless PTT matches that of the Receiving PTT. If they do not match, contact your vendor or follow the instruction of **Rematching Wireless PTT**.
2. Each time before connecting the boom mic headset to the radio, please turn off the radio and then turn it on after the boom mic is connected.
3. Keep the Receiving PTT at least 3cm away from the antenna when using. Otherwise the working range could be shortened. A working range of 1.5m between the Wireless PTT and Receiving PTT is guaranteed if the instruction is followed.
4. The Speaker should have a roger beep and the radio on/off LED should be turned on when the wireless PTT is pressed.


Operating Instruction

1. Velcro the wireless PTT to finger or other devices such as motorcycle handle bar or a gun shaft.
2. Wear the Ear Hook around the ear, with the Speaker facing the ear and Boom Mic pointing the mouth.

3. Turn off the radio and plug the connector of the boom mic headset to the radio. Then turn the radio back on.
4. Secure the clip in line onto clothes to avoid cable rubbing.

Rematching Wireless PTT

1. Wireless PTT and Receiving PTT are prematched when out of factory.
2. Each time when you match the Wireless PTT with Receiving PTT, the Receiving PTT will adopt the unique Wireless PTT serial. **Do not match your Receiving PTT with others' Wireless PTT** to avoid one Wireless PTT controlling more than one Receiving PTT.
3. To rematch a new Wireless PTT:
 - 1) turn off the radio and plug the boom mic headset to the radio.
 - 2) Press the Learning Button on the back of the Receiving PTT (see *Pic B*). You should hear a very distinct clinking sound which means the Learning Button is pressed.
 - 3) Turn the radio back on while keeping the Learning Button pressed.
 - 4) Press the Wireless PTT while keeping the Learning Button pressed. You should see the on/off LED turning red and hear a roger beep in the Speaker.
 - 5) Release both Learning Button and Wireless PTT.
 - 6) Remark the serial number on the Receiving PTT to match that of the new Wireless PTT.



Maintenance

There is current draw when the Wireless PTT is pushed. Please make sure it is not pressed when stored.

FCC Caution

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference
2. This device must accept any interference received, including interference that may cause undesired operation.

FCC Notes

The manufacturer is not responsible for and radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.