




Freq. Stability NVNT ac20 5785MHz Sum




Freq. Stability NVNT ac20 5825MHz Sum




Freq. Stability NVNT ac40 5190MHz Ant1




Freq. Stability NVNT ac40 5230MHz Ant1




Freq. Stability NVNT ac40 5270MHz Ant1




Freq. Stability NVNT ac40 5310MHz Ant1




Freq. Stability NVNT ac40 5510MHz Ant1




Freq. Stability NVNT ac40 5590MHz Ant1




Freq. Stability NVNT ac40 5670MHz Ant1




Freq. Stability NVNT ac40 5755MHz Ant1




Freq. Stability NVNT ac40 5795MHz Ant1




Freq. Stability NVNT ac40 5190MHz Ant2




Freq. Stability NVNT ac40 5230MHz Ant2



Freq. Stability NVNT ac40 5270MHz Ant2




Freq. Stability NVNT ac40 5310MHz Ant2




Freq. Stability NVNT ac40 5510MHz Ant2







Freq. Stability NVNT ac40 5590MHz Ant2




Freq. Stability NVNT ac40 5670MHz Ant2




Freq. Stability NVNT ac40 5755MHz Ant2




Freq. Stability NVNT ac40 5795MHz Ant2




Freq. Stability NVNT ac40 5190MHz Sum




Freq. Stability NVNT ac40 5230MHz Sum




Freq. Stability NVNT ac40 5270MHz Sum




Freq. Stability NVNT ac40 5310MHz Sum




Freq. Stability NVNT ac40 5510MHz Sum




Freq. Stability NVNT ac40 5590MHz Sum




Freq. Stability NVNT ac40 5670MHz Sum




Freq. Stability NVNT ac40 5755MHz Sum




Freq. Stability NVNT ac40 5795MHz Sum



Freq. Stability NVNT ac80 5210MHz Ant1




Freq. Stability NVNT ac80 5290MHz Ant1




Freq. Stability NVNT ac80 5530MHz Ant1







Freq. Stability NVNT ac80 5610MHz Ant1




Freq. Stability NVNT ac80 5690MHz Ant1




Freq. Stability NVNT ac80 5775MHz Ant1




Freq. Stability NVNT ac80 5210MHz Ant2




Freq. Stability NVNT ac80 5290MHz Ant2



Freq. Stability NVNT ac80 5530MHz Ant2



Freq. Stability NVNT ac80 5610MHz Ant2



Freq. Stability NVNT ac80 5690MHz Ant2