




Freq. Stability NVNT ax20 5745MHz Ant1




Freq. Stability NVNT ax20 5785MHz Ant1




Freq. Stability NVNT ax20 5825MHz Ant1




Freq. Stability NVNT ax20 5180MHz Ant2




Freq. Stability NVNT ax20 5200MHz Ant2




Freq. Stability NVNT ax20 5240MHz Ant2




Freq. Stability NVNT ax20 5260MHz Ant2




Freq. Stability NVNT ax20 5280MHz Ant2




Freq. Stability NVNT ax20 5320MHz Ant2




Freq. Stability NVNT ax20 5500MHz Ant2




Freq. Stability NVNT ax20 5600MHz Ant2




Freq. Stability NVNT ax20 5700MHz Ant2




Freq. Stability NVNT ax20 5745MHz Ant2



Freq. Stability NVNT ax20 5785MHz Ant2




Freq. Stability NVNT ax20 5825MHz Ant2




Freq. Stability NVNT ax20 5180MHz Sum







Freq. Stability NVNT ax20 5200MHz Sum




Freq. Stability NVNT ax20 5240MHz Sum




Freq. Stability NVNT ax20 5260MHz Sum




Freq. Stability NVNT ax20 5280MHz Sum




Freq. Stability NVNT ax20 5320MHz Sum




Freq. Stability NVNT ax20 5500MHz Sum




Freq. Stability NVNT ax20 5600MHz Sum




Freq. Stability NVNT ax20 5700MHz Sum




Freq. Stability NVNT ax20 5745MHz Sum




Freq. Stability NVNT ax20 5785MHz Sum




Freq. Stability NVNT ax20 5825MHz Sum




Freq. Stability NVNT ax40 5190MHz Ant1




Freq. Stability NVNT ax40 5230MHz Ant1



Freq. Stability NVNT ax40 5270MHz Ant1




Freq. Stability NVNT ax40 5310MHz Ant1




Freq. Stability NVNT ax40 5510MHz Ant1







Freq. Stability NVNT ax40 5590MHz Ant1




Freq. Stability NVNT ax40 5670MHz Ant1




Freq. Stability NVNT ax40 5755MHz Ant1




Freq. Stability NVNT ax40 5795MHz Ant1




Freq. Stability NVNT ax40 5190MHz Ant2



Freq. Stability NVNT ax40 5230MHz Ant2



Freq. Stability NVNT ax40 5270MHz Ant2



Freq. Stability NVNT ax40 5310MHz Ant2