
- Input voltage: 3V (CR2430)
- Emission Frequency: 433.92MHz ± 100KHz
- Emission Power: 10 milliwatt
- Work temperature:-10°C -50°C
- Emission distance: open 200m, two walls 30m

#### Manual direction of DC305 DC306 DC307 DC313

- Transmitter: You can choose single channel (DC 305), five channels (DC 306). Each indicator light means one control channel. Press 'channel choose' button P1- (indicator move left side) or P1+ (indicator move right side) to change the channel. On the analogy of this, loose finger when the indicator light move to suitable channel that you select effective channel. All indicator lights flash that means all channels is effective (group control state).
- Transmitter: You can choose nine channels (DC 307), fifteen channels (DC313). One number of LCD screen means one control channel. Press 'channel choose' button Pi- (number descending) or PI+ (number increasing) to change the channel. On the analogy of this, loose finger when the indicator light move to suitable channel that you select effective channel. If LCD screen number show o that means all channels is effective (group control state).
- Notice: transmitter Do not exposed to moisture and strike, so as not to affect life. When you use transmitter, if found emission distance obviously short or less sensitive, please change another same new battery. Please have batteries for recycling.
- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.






### Matchable DC41/42 Set up



The interval of different button must within 10 seconds of all setting, otherwise the system will restore the original state



One receiver store 20 emitters channels at most, and one channel of emitter can control 20 receivers at most.





### Matchable DC43 Set up

programming key




The interval of different button must within 10 seconds of all setting, otherwise the system will restore the original state

long flashing



One receiver store 20 emitters channels at most, and one channel of emitter can control 20 receivers at most.

and extinguished





# Control System

# DC305 DC306 DC307 DC313 Control System **Specification**

Version No.: A/00



## Type Specification

