

# 無線燒錄器 Wireless Programming Tool

Model: UNI-PT01

### **FCC Notices**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is

guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- --Reorient or relocate the receiving antenna.
- --Increase the separation between the equipment and receiver.
- --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

#### **CAUTION:**

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

#### RF exposure warning:

The equipment complies with FCC RF exposure limits set forth for an uncontrolled environment.

The equipment must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

## Specification

Operating Humidity	Max 95 %
Storage Temperature	0°C to 65 °C
Operation Temperature	0°C to 45 °C
Transmitting Power	Max 19.2μv/m
Transmitting Frequency	125kHz
Type of modulation	ASK

## Systems Operation

- Step 1. Select vehicle by Maker.
- Step 2. Select vehicle model & year.
- Step 3. Select "PROGRAM" •
- Step 4. Put the sensor into the tool slot.
- Step 5. Enter "PROGRAM mode" to program.
  - 1. Clone ID
  - 2. Input ID
  - 3. Blank Sensor