

RW-TH68N Thank you for purchasing a Rosewill Bluetooth Headphones. Please read the instruction manual before use and retain for future reference.

P4(封底)

## CAUTION

К

- Please charge the battery if you can not turn on the headphones
- Please turn off the headphones after use to maintain a longer battery life

P1(##

122 518 196

- Please use USB cable included in the package for battery charging
- Please do not change any other battery
- Please do not keep headphones in a wet environment
- · Do not exposure or toss headphones into fire
- Please do not try to disassemble the headphones

### **PRODUCT OVERVIEW**

# INSTRUCTIONS

### **Battery Charging**

- Battery: Rechargeable Polymer Lithium-Ion Battery (DC: 3.7V/290 mAh).
- Power: Please use the USB DC5V cable included in the package for charging.
- Charging Time: When charging for the first time, please be sure the battery is charged more than 4 hours to be fully charged. After the first time, charging time is about 3 hours.
- When the red light is on, the headphones are in charge mode. The red light will turn off when the battery is fully charged.

## **Noise Cancellation Function**

When you slide the NC button to the ON (the red mark) side, the indicator will turn on, then you can enjoy the headphones in Noise Cancellation mode. When you do not need the Noise Cancellation function, slide the NC button to the OFF side.

#### **Pairing Headphones with Bluetooth Devices**

- Turn the headphones on by holding down the MFB button until you hear the voice say "ON". To turn off, hold down the same button until you hear the voice say "OFF".
- Please keep the headphones and mobile phone in the range of 1 meter when pairing and make sure your headphones are off.
- Press and hold the MFB button for 5 seconds to put the headphones in paring mode (if successful the LED light will flash red and blue).
- Go into the Bluetooth settings on your device, search for new Bluetooth devices and select RW-TH68N.
- The LED light will blink blue when the headphones are successfully paired.

Notes: If the pairing is not successful, please turn the headphones off and on, then try to pair again.

FUNCTION	STATUS	OPERATION
Redial Last number	Standby mode	Quickly short press MFB twice
Volume up	Conversation mode	Short press Volume + button
Volume down	Conversation mode	Short press Volume - button
Answer call	Ringing	Short press MFB button
Reject call	Ringing	Press and hold MFB button for one second, then release when you hear indication sound
Transfer the call between headphones and Bluetooth device	Conversation mode	Press and hold the MFB button for 3 seconds to transfer the conversation from headphones to mobile phone. Then press and hold the MFB button for 3 seconds to transfer the conversation back from mobile phone to headphones.

#### Making Calls with the Headphones

Notes:

- Not all mobile phones support every function listed above. Please refer to the instructions of your mobile phone.
- Some functions and indication tones may vary with mobile phones.

#### **Playing Music**

When the headphones connect with the mobile phone or Bluetooth transmitter, you can enjoy music through headphones wirelessly.

FUNCTION	STATUS	OPERATION
Pause	Playing music	Short press MFB button
Play	Pausing	Short press MFB button
Next track	Playing music	Short press Volume + button
Previous track	Playing music	Short press Volume - button
Volume up	Playing music	Long press Volume + button
Volume down	Playing music	Long press Volume - button

# **SPECIFICATIONS**

Bluetooth Solution: CSR 8635 Bluetooth Version: V5.0 Support Agreement: A2DP, AVRCP, HFP, HSP Operating Distance: 10 m Battery: 290 mAh Charging Time: about 3 hrs Charging Current: 170 mA Music Playing Time: 16 hrs (50% volume) Talking Time: 18 hrs (50% volume) Driver Unit: 40 mm Sensitivity: 105 dB/1 mW (SPL at 1 kHz)

Impedance: 32Ω

Frequency Range: 20 Hz-20 kHz

## FCC WARNING

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.





Technical Support Information techsupport@rosewill.com 1-800-575-9885 Please register your product at www.rosewill.com for complete warranty information and support for your product.

RW-TH68N\_A