

USER MANUAL



1. 3.5mm earphone plug
2. DC jack for car charger
3. Power On/Off/switch wireless Transmitter On/off button.
4. LCD display
5. Set button
6. Channel up/down selector
7. M1/M2/M3 button (Memory1,2,3)

DEVICE OVERVIEW

1. Battery operation: (Batteries not included)

Carefully open the battery cover on the rear of the FM transmitter and insert 2 x 1.2V Ni-MH rechargeable batteries into the battery compartment. Please ensure that they are inserted in accordance with the polarity markings, or the unit will not work.

Note: When the unit is used with the car power adaptor, or if it will not be used for a long period of time, please remove the batteries to avoid damaging the set from battery leakage.

Do not mix battery types; only use the batteries of the same type for the set. when inserting new batteries, do not try to mix old batteries with the new ones.

3. Turn on/off the FM transmitter

Press the on/off button for 3 seconds to turn on or off the unit.

4. Setup procedure:

- a. Press and hold to on/off button for 3 seconds to turn on the transmitter.
- b. Press the on/off button once to turn on FM transmission mode. The FM frequency will be display.
- c. Plug the 3.5mm stereo cable into your audio device (Portable audio player, CD player or mobile).
- d. Press the up/down button to select the desired channel from 88.1-107.9 MHz.
- e. On the car FM radio, turn to the same frequency with the FM transmitter.
- f. Adjust the volume on the connected device and your car radio volume.

Note:

If there is any interference with local area radio station, select another frequency for use with the FM transmitter.

5. Programming the channels:

The FM Transmitter has 3 programmable channels, select the channel you want to store then press M1/M2/M3 button for about 3 seconds to store current FM frequency. When you want to select the frequency directly just press M1/M2 or M3 button.

6. Set the time

When the unit is transmitting, long press SET to activate setting of time. Complete setting through pressing UP/DOWN and SET to confirm. The sequence is as follows: hour-> minutes

7. Set the LED light

Press both UP/DOWN at the same time to turn on the LED light, press both UP/DOWN again to turn off the LED light.

8. Specification

Power Source: DC 3V (Use 2x 1.2V Ni-MH Rechargeable Batteries Only) or external power supply DC12-24V

Battery Warning

Only 1.2V Ni-MH rechargeable batteries is allowed to use for this product!

Non-rechargeable batteries are not to be allowed!

Batteries are to be inserted with the correct polarity.

Do not mix different types of batteries or new and used batteries. Rechargeable batteries are only to be charged under adult supervision.

Remove batteries from the unit when not in use for extended time or when batteries become exhausted.

Dispose of batteries responsibly.

Do not dispose of in fire.

The batteries will start to charge when connect the provided car adapter to car cigarette socket.

When the batteries are fully charged, it is recommended to disconnect the car adapter.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

为折叠线，不要印出来，
说明书需折叠好！

尺寸公差			材质		品名	F2A客定说明书	比例	1:1	日期	2018.09.19
位数	尺寸	角度	80g书写纸 4色印刷	2012.07.12	料号	SMS-F2A-02-121025 (1607100301)	设计	彭永亮	审核	
X . X	±0.1	±0.5°			版本	E	制图		批准	
X . XX	±0.05	±0.5°			更改了内容					
A			2012.07.12		E		制图		DRAWN	
记事			变更NO.		年/月/日		深圳市欧诺达电子科技有限公司 SHENZHEN ONUODA ELECTRONICS TECHNOLOGY CO., LTD		SIZE: 297*210mm	