








To LF 125KHz
channel:

Inside this black
frame we have the
125KHz antenna coil.
Connect to the PCB
with the 2 black
wires and connector

To HF 13.56MHz
channel:

These printed lines
on the PCB are the
HF antenna for the
13.56MHz channel

