


Below 1GHz: EUT is placed on the center of the turn table



Below 1GHz: EUT is placed on the center of the turn table



Above 1GHz: EUT is placed on the center of the turn table



Above 1GHz: EUT is placed on the center of the turn table