FIGURE 1 LED LCD TV (M/N: 46K360M) COVER REMOVED




FIGURE 2 LED LCD TV (M/N: 46K360M) PANEL LABEL





FIGURE 4 LED LCD TV (M/N: 46K360M) Power Board (Soldered Side)



FIGURE 5 LED LCD TV (M/N: 46K360M) MAIN BOARD (COMPONENT SIDE)



FIGURE 6 LED LCD TV (M/N: 46K360M) MAIN BOARD (SOLDERED SIDE)



FIGURE 7 LED LCD TV (M/N: 46K360M) TUNER ON MAIN BOARD



FIGURE 8 LED LCD TV (M/N: 46K360M) CHIP #1 & CRYSTAL ON MAIN BOARD



FIGURE 9 LED LCD TV (M/N: 46K360M) KEY BOARD (COMPONENT SIDE)




FIGURE 10 LED LCD TV (M/N: 46K360M) KEY BOARD (SOLDERED SIDE)




FIGURE 11 LED LCD TV (M/N: 46K360M) IR BOARD (COMPONENT SIDE)




FIGURE 12 LED LCD TV (M/N: 46K360M) IR BOARD (SOLDERED SIDE)



FIGURE 13 LED LCD TV (M/N: 46K360M) LCD PANEL CONTROL BOARD (COMPONENT SIDE)



Figure 14 LED LCD TV (M/N: 46K360M) LCD PANEL CONTROL BOARD (SOLDERED SIDE)

