

FIGURE 1
LCD TV (M/N: 47LC55S240V87)
COVER REMOVED



FIGURE 2
LCD TV (M/N: 47LC55S240V87)
IR BOARD (COMPONENT SIDE)




FIGURE 3
LCD TV (M/N: 47LC55S240V87)
IR BOARD (SOLDERED SIDE)




FIGURE 4
LCD TV (M/N: 47LC55S240V87)
KEY BOARD (COMPONENT SIDE)




FIGURE 5
LCD TV (M/N: 47LC55S240V87)
KEY BOARD (SOLDERED SIDE)




FIGURE 6
LCD TV (M/N: 47LC55S240V87)
LCD POWER BOARD S (COMPONENT SIDE)




FIGURE 7
LCD TV (M/N: 47LC55S240V87)
LCD POWER BOARD S (SOLDERED SIDE)




FIGURE 8
LCD TV (M/N: 47LC55S240V87)
LCD POWER BOARD M (COMPONENT SIDE)




FIGURE 9
LCD TV (M/N: 47LC55S240V87)
LCD POWER BOARD M (SOLDERED SIDE)




FIGURE 10
LCD TV (M/N: 47LC55S240V87)
POWER BOARD (COMPONENT SIDE)



FIGURE 11
LCD TV (M/N: 47LC55S240V87)
POWER BOARD (SOLDERED SIDE)




FIGURE 12
LCD TV (M/N: 47LC55S240V87)
MAIN BOARD (COMPONENT SIDE)



FIGURE 13
LCD TV (M/N: 47LC55S240V87)
MAIN BOARD (SOLDERED SIDE)




FIGURE 14
LCD TV (M/N: 47LC55S240V87)
LABEL ON TUNER



FIGURE 15
LCD TV (M/N: 47LC55S240V87)
CRYSTAL #1 ON MAIN BOARD



FIGURE 16
LCD TV (M/N: 47LC55S240V87)
CHIP #2 ON MAIN BOARD



FIGURE 17
LCD TV (M/N: 47LC55S240V87)
CRYSTAL ON MAIN BOARD



FIGURE 18
LCD TV (M/N: 47LC55S240V87)
CONTROL BOARD (COMPONENT SIDE)




FIGURE 19
LCD TV (M/N: 47LC55S240V87)
CONTROL BOARD (SOLDERED SIDE)




FIGURE 20
LCD TV (M/N: 47LC55S240V87)
CHIP ON LCD PANEL CONTROL BOARD



FIGURE 21
LCD TV (M/N: 47LC55S240V87)
CRYSTAL ON LCD PANEL CONTROL BOARD



FIGURE 22
LCD TV (M/N: 47LC55S240V87)
LABEL ON LCD PANEL



FIGURE 23
LCD TV (M/N: 47LC55S240V87)
DEBUG #1



FIGURE 24
LCD TV (M/N: 47LC55S240V87)
DEBUG #2



FIGURE 25
LCD TV (M/N: 47LC55S240V87)
DEBUG #3



FIGURE 26
LCD TV (M/N: 47LC55S240V87)
DEBUG #4



FIGURE 27
LCD TV (M/N: 47LC55S240V87)
DEBUG #5

