

FIGURE 1
LED LCD TV (M/N: 55K610GWN)
COVER REMOVED



FIGURE 2
LED LCD TV (M/N: 55K610GWN)
PANEL LABEL



FIGURE 3
LED LCD TV (M/N: 55K610GWN)
POWER BOARD (COMPONENT SIDE)



FIGURE 4
LED LCD TV (M/N: 55K610GWN)
POWER BOARD (SOLDERED SIDE)




FIGURE 5
LED LCD TV (M/N: 55K610GWN)
MAIN BOARD (COMPONENT SIDE)



FIGURE 6
LED LCD TV (M/N: 55K610GWN)
MAIN BOARD (SOLDERED SIDE)



FIGURE 7
LED LCD TV (M/N: 55K610GWN)
TUNER ON MAIN BOARD



FIGURE 8
LED LCD TV (M/N: 55K610GWN)
WIRELESS N USB MODULE



FIGURE 9
LED LCD TV (M/N: 55K610GWN)
CHIP #1 & CRYSTAL #1 ON MAIN BOARD



FIGURE 10
LED LCD TV (M/N: 55K610GWN)
CHIP #2 & CRYSTAL #2 ON MAIN BOARD




FIGURE 11
LED LCD TV (M/N: 55K610GWN)
KEY BOARD (COMPONENT SIDE)




FIGURE 12
LED LCD TV (M/N: 55K610GWN)
KEY BOARD (SOLDERED SIDE)



FIGURE 13
LED LCD TV (M/N: 55K610GWN)
IR BOARD (COMPONENT SIDE)




FIGURE 14
LED LCD TV (M/N: 55K610GWN)
IR BOARD (SOLDERED SIDE)




FIGURE 15
LED LCD TV (M/N: 55K610GWN)
LCD PANEL CONTROL BOARD (COMPONENT SIDE)



FIGURE 16
LED LCD TV (M/N: 55K610GWN)
LCD PANEL CONTROL BOARD (SOLDERED SIDE)



FIGURE 18
LED LCD TV (M/N: 55K610GWN)
DEBUG 1




FIGURE 19
LED LCD TV (M/N: 55K610GWN)
DEBUG 2

