

FIGURE 1
LED LCD TV (M/N: 50K370GW)
COVER REMOVED



FIGURE 2
LED LCD TV (M/N: 50K370GW)
POWER BOARD (COMPONENT SIDE)




FIGURE 3
LED LCD TV (M/N: 50K370GW)
POWER BOARD (SOLDERED SIDE)




FIGURE 4
LED LCD TV (M/N: 50K370GW)
MAIN BOARD (COMPONENT SIDE)



FIGURE 5
LED LCD TV (M/N: 50K370GW)
MAIN BOARD (SOLDERED SIDE)




FIGURE 8
LED LCD TV (M/N: 50K370GW)
CRYSTAL #2 ON MAIN BOARD



FIGURE 9
LED LCD TV (M/N: 50K370GW)
KEY BOARD (COMPONENT SIDE)



FIGURE 10
LED LCD TV (M/N: 50K370GW)
KEY BOARD (SOLDERED SIDE)




FIGURE 11
LED LCD TV (M/N: 50K370GW)
RF BOARD (COMPONENT SIDE)




FIGURE 12
LED LCD TV (M/N: 50K370GW)
RF BOARD (SOLDERED SIDE)



FIGURE 13
LED LCD TV (M/N: 50K370GW)
LCD PANEL CONTROL BOARD (COMPONENT SIDE)



FIGURE 14
LED LCD TV (M/N: 50K370GW)
LCD PANEL CONTROL BOARD (SOLDERED SIDE)




FIGURE 15
LED LCD TV (M/N: 50K370GW)
CHIP ON LCD PANEL CONTROL BOARD

