

FIGURE 1
SERO 7 PRO (M/N: M470BSA)
GENERAL APPEARANCE (FRONT VIEW)




FIGURE 2
SERO 7 PRO (M/N: M470BSA)
GENERAL APPEARANCE (BACK VIEW)



FIGURE 3
SERO 7 PRO (M/N: M470BSA)
PORTS



FIGURE 13
SERO 7 PRO (M/N: M470BSA)
USB CABLE




FIGURE 14
SERO 7 PRO (M/N: M470BSA)
ADAPTER (GENERAL APPEARANCE)




FIGURE 15
SERO 7 PRO (M/N: M470BSA)
ADAPTER (USB PORT)



FIGURE 16
SERO 7 PRO (M/N: M470BSA)
ADAPTER (GENERAL APPEARANCE – LABEL)

